

STANDING DATA FOR MSATS

PREPARED BY: AEMO MARKETS
VERSION: 4.6
EFFECTIVE DATE: 14 MARCH 2022
STATUS: FINAL

Approved for distribution and use by:

APPROVED BY: Peter Geers
TITLE: Chief Strategy and Markets Officer

DATE: 27 August 2020

PREPARED BY: AEMO Markets
DOCUMENT REF:
VERSION: 5.1
EFFECTIVE DATE: 1 May 2022
STATUS: Draft



Approved for distribution and use by:

APPROVED BY: Violette Mouchaileh
TITLE: Chief Markets Officer

DATE: TBD

VERSION RELEASE HISTORY

| Version | Effective Date | Summary of Changes |
|---------------------|----------------------------|--|
| 4.0 | Aug 2009 | Update to AEMO Format |
| 4.1 | 19/04/2012 | Updates to NMI Data tables to include Feeder Class, Customer Classification Code & Customer Threshold Code and minor data corrections. |
| 4.2 | 28/08/2013 | Updated wording for Nx suffixes in sections 8, 9 and 12. Updated reference to the CATS procedures for Embedded Networks in section 7. Added new data stream type codes under section 11: Reference Tables. Updated reference to the NEM Metrology Procedures in section 15. |
| 4.3 | 01 December 2017 | Updated to incorporate: <ul style="list-style-type: none"> National Electricity Amendment (Expanding competition in metering and related services) Rule 2015. No.12; National Electricity Amendment (Embedded Networks) Rule 2015 No. 15; and National Electricity Amendment (Meter Replacement Processes) Rule 2016 No. 2. |
| 4.4 | 01 December 2017 | Final Version |
| 4.5 | 1 October 2021 | Updated to incorporate amendments for National Electricity Amendment (Five Minute Settlement) Rule 2017 No. 15 and National Electricity Amendment (Global Settlement and Market Reconciliation) Rule 2018 No 14. |
| 4.6 | 14 March 2022 | MSATS Standing Data Review Phase 1 – New and amended fields |
| 5.1 | 1 May 2022 | Updated as part of Retail Electricity Market Procedures March 2021 Consultation |

CONTENTS

| | | |
|-------|--|--------------------|
| 1. | INTRODUCTION | <u>76</u> |
| 1.1. | Purpose and scope | <u>76</u> |
| 1.2. | Definitions and interpretation | <u>76</u> |
| 1.3. | Related documents | <u>76</u> |
| 2. | BACKGROUND | <u>76</u> |
| 3. | CONVENTIONS USED WITHIN THIS DOCUMENT | <u>87</u> |
| 3.1. | Column Headed: Standing Data Required | <u>87</u> |
| 3.2. | NMIs Affected | <u>87</u> |
| 4. | CATS_METER_REGISTER | <u>98</u> |
| 5. | CATS_DLF_CODES | <u>1847</u> |
| 6. | CATS_EMB_NET_ID_CODES | <u>1948</u> |
| 7. | CATS_NMI_DATA | <u>2049</u> |
| 8. | CATS_NMI_DATA_STREAM | 23 |
| 9. | CATS_REGISTER_IDENTIFIER | <u>2524</u> |
| 10. | CATS_NMI_PARTICIPANT_RELATIONS | <u>2827</u> |
| 11. | REFERENCE TABLES | <u>2928</u> |
| 12. | USE OF NMI SUFFIX TO POPULATE CATS_REGISTER_IDENTIFIER | <u>3938</u> |
| 13. | ASSIGNMENT OF DATA – ACCUMULATION METERS | <u>4039</u> |
| 13.1. | Single Meter, no controlled load | <u>4039</u> |
| 13.2. | Two Single Element Meters, no controlled load | <u>4140</u> |
| 13.3. | Two Single Element Meters, one with controlled load | <u>4140</u> |
| 13.4. | One Meter with Two Registers, one measuring a controlled load | <u>4140</u> |
| 13.5. | Single Multi-function Meter | <u>4241</u> |
| 13.6. | Two meters, three registers. One register measures a controlled load | <u>4241</u> |
| 14. | ASSIGNMENT OF DATA – INTERVAL METERS | <u>4342</u> |
| 14.1. | One meter | <u>4342</u> |
| 14.2. | Import/Export meter | <u>4342</u> |
| 14.3. | One meter: multiple registers | <u>4443</u> |
| 14.4. | One meter: Twin Measurement Elements | <u>4443</u> |
| 15. | ASSIGNMENTS OF DATA – SAMPLE METERS | <u>4645</u> |
| 15.1. | Multifunction Sample Meter | <u>4645</u> |
| 16. | CROSS REFERENCE OF BROWSER AND ASEXML DATA ELEMENTS | <u>4746</u> |

| | | |
|-----|----------------------------------|-------------|
| 17. | EXAMPLES OF TYPICAL FIELD VALUES | <u>5857</u> |
| 18. | DATA TYPE CONVENTIONS | <u>6564</u> |

TABLES

| | | |
|----------|---|-------------|
| Table 1 | MSATS Master Tables | <u>76</u> |
| Table 2 | Explanation of Standing Data Requirements | <u>87</u> |
| Table 3 | CATS_METER_REGISTER | <u>98</u> |
| Table 4 | CATS_DLF_CODES..... | <u>1847</u> |
| Table 5 | CATS_EMB_NET_ID_CODES..... | <u>1948</u> |
| Table 6 | CATS_NMI_DATA | <u>2049</u> |
| Table 7 | CATS_NMI_DATA_STREAM | <u>2423</u> |
| Table 8 | CATS_REGISTER_IDENTIFIER..... | <u>2524</u> |
| Table 9 | CATS_NMI_PARTICIPANT_RELATIONS | <u>2827</u> |
| Table 10 | - Valid Aggregate Codes..... | <u>2928</u> |
| Table 11 | - Valid Consumption Type Codes..... | <u>2928</u> |
| Table 12 | - Valid Datastream Type Codes..... | <u>2928</u> |
| Table 13 | - Valid Profile Codes | <u>29</u> |
| Table 14 | Valid Transformer Fields values | <u>3029</u> |
| Table 15 | Valid Meter Use Codes | <u>3736</u> |
| Table 16 | Valid Time of Day Codes..... | <u>3736</u> |
| Table 17 | Valid Controlled Load Codes | <u>3837</u> |
| Table 18 | Valid Test Result Codes..... | <u>3837</u> |
| Table 19 | Valid Transformer Test Values..... | <u>3837</u> |
| Table 20 | Valid Shared Isolation Point Flag Values..... | <u>3837</u> |
| Table 21 | Example CATS_NMI_DATA_STREAM | <u>4039</u> |
| Table 22 | Example CATS_REGISTER_IDENTIFIER..... | <u>4039</u> |
| Table 23 | Example CATS_NMI_DATA_STREAM | <u>4140</u> |
| Table 24 | Example CATS_REGISTER_IDENTIFIER..... | <u>4140</u> |
| Table 25 | Example CATS_NMI_DATA_STREAM | <u>4140</u> |
| Table 26 | Example CATS_REGISTER_IDENTIFIER..... | <u>4140</u> |
| Table 27 | Example CATS_NMI_DATA_STREAM | <u>4140</u> |
| Table 28 | Example CATS_REGISTER_IDENTIFIER..... | <u>4140</u> |
| Table 29 | Example CATS_NMI_DATA_STREAM | <u>4244</u> |
| Table 30 | Example CATS_REGISTER_IDENTIFIER..... | <u>4244</u> |
| Table 31 | Example CATS_NMI_DATA_STREAM | <u>4244</u> |
| Table 32 | Example CATS_REGISTER_IDENTIFIER..... | <u>4244</u> |
| Table 33 | Example CATS_NMI_DATA_STREAM | <u>4342</u> |
| Table 34 | Example CATS_REGISTER_IDENTIFIER..... | <u>4342</u> |
| Table 35 | Example CATS_NMI_DATA_STREAM | <u>4342</u> |
| Table 36 | Example CATS_REGISTER_IDENTIFIER..... | <u>4342</u> |

| | | |
|----------|---------------------------------------|-----------------|
| Table 37 | Example CATS_NMI_DATA_STREAM | 4443 |
| Table 38 | Example CATS_REGISTER_IDENTIFIER..... | 4443 |
| Table 39 | Example CATS_NMI_DATA_STREAM | 4443 |
| Table 40 | Example CATS_REGISTER_IDENTIFIER..... | 4544 |
| Table 41 | Example CATS_NMI_DATA_STREAM | 4544 |
| Table 42 | Example CATS_REGISTER_IDENTIFIER..... | 4544 |
| Table 43 | Example CATS_NMI_DATA_STREAM | 4645 |
| Table 44 | Example CATS_REGISTER_IDENTIFIER..... | 4645 |
| Table 45 | CATS_Meter_Register..... | 4746 |
| Table 46 | CATS_DLF_Codes | 5049 |
| Table 47 | CATS_Emb_Net_ID_Codes | 5150 |
| Table 48 | CATS_NMI_Data..... | 5254 |
| Table 49 | CATS_Register_Identifier | 5655 |
| Table 50 | CATS_NMI_Participant_Relations..... | 5756 |
| Table 51 | CATS_Meter_Register..... | 5958 |
| Table 52 | CATS_DLF_Codes | 6264 |
| Table 53 | CATS_Emb_Net_ID_Codes | 6264 |
| Table 54 | CATS_NMI_Data..... | 6264 |
| Table 55 | CATS_NMI_Data_Stream | 6463 |
| Table 56 | CATS_Register_Identifier | 6463 |

1. INTRODUCTION

1.1. Purpose and scope

This document details the data requirements for the various data elements comprising the CATS Standing Data stored for each *NMI*, together with relevant examples and definitions.

This document forms part of each of the Retail Electricity Market Procedures and will be amended when another Retail Electricity Market Procedure requires amendment. The consultation process applicable to the relevant Retail Electricity Market Procedure will also apply to the necessary amendments to this document.

1.2. Definitions and interpretation

The Retail Electricity Market Procedures – Glossary and Framework:

- a) is incorporated into and forms part of this document; and
- b) should be read with this document.

1.3. Related documents

| Title | Location |
|---|---|
| Retail Electricity Market Procedures – Glossary and Framework | http://aemo.com.au/Electricity/National-Electricity-Market-NEM/Retail-and-metering/Glossary-and-Framework |
| CATS Procedures | http://www.aemo.com.au/Electricity/National-Electricity-Market-NEM/Retail-and-metering/Market-Settlement-and-Transfer-Solutions |
| WIGS Procedures | http://www.aemo.com.au/Electricity/National-Electricity-Market-NEM/Retail-and-metering/Market-Settlement-and-Transfer-Solutions |
| MDM Procedures | http://www.aemo.com.au/Electricity/National-Electricity-Market-NEM/Retail-and-metering/Market-Settlement-and-Transfer-Solutions |
| MSATS CATS history Model | http://www.aemo.com.au/Electricity/National-Electricity-Market-NEM/Retail-and-metering/Market-Settlement-and-Transfer-Solutions |
| MSATS guides | http://www.aemo.com.au/Electricity/National-Electricity-Market-NEM/Retail-and-metering/Market-Settlement-and-Transfer-Solutions |

2. BACKGROUND

The five MSATS master tables contain the standing data stored for each *NMI*. They are the following:

Table 1 MSATS Master Tables

| Table | Summary of Contents |
|--------------------------------|--|
| CATS_NMI_DATA | Address, TNI Code, DLF Code, aggregate flag, embedded network names, Jurisdiction, NMI status code, etc |
| CATS_NMI_PARTICIPANT_RELATIONS | Roles and associated Participants. Separate records are maintained for each Role/Participant relationship. |
| CATS_NMI_DATA_STREAM | Suffix, ADL Code, Profile Name, Datastream type and datastream status of each MDM Datastream. |
| CATS_METER_REGISTER | Meter Serial ID, meter type, meter manufacturer, test results, etc |
| CATS_REGISTER_IDENTIFIER | Meter Serial ID, Network Tariff Code, unit of measure etc |

For a *NMI* to be capable of being used in MSATS, it must have the following minimum set of data:

- At least one record on the CATS_NMI_DATA table; and
- At least eight records on the CATS_NMI_PARTICIPANT_RELATIONS table, one for each of the mandatory roles (ROLR, LNSP, LR, RP, FRMP, MDP, MPC and MPB).

It will also normally have:

- At least one record on each of the CATS_METER_REGISTER and CATS_REGISTER_IDENTIFIER (there should be at least one record for each *meter* and register associated with the *NMI*) tables.

NMIs may or may not have:

- Records on the CATS_NMI_DATA_STREAM table. If *metering data* is to be submitted to MDM there must be at least one valid record on this table.

Every time a change is made to any of the data in any of these tables, the old records are made inactive and new records are created, thus ensuring that there is a complete history of all changes.

3. CONVENTIONS USED WITHIN THIS DOCUMENT

The format of the data fields in the "Browser Format Column" column of Tables is as defined in section 18.

The following information defines the coded entries in columns used in Tables 3 - 9.

3.1. Column Headed: Standing Data Required

The column indicates the requirement to provide this data to MSATS.

Table 2 Explanation of Standing Data Requirements

| Requirement | Description |
|------------------|--|
| MANDATORY | Transfer, Validation or processing cannot proceed without this data. |
| REQUIRED | This data must be provided if this information is available. |
| OPTIONAL | This data is not required, but will be accepted if delivered. |
| Address Option 1 | AEMO's preferred address option. If the applicable fields labelled "Address Option 1" cannot be provided, "Address Option 2" is MANDATORY. |
| Address Option 2 | AEMO's non-preferred address option. If Address Option 1 is provided, these fields are not to be supplied. |

3.2. NMIs Affected

Data must be provided for every *NMI* in MSATS. The *NMIs* that must be registered in MSATS are:

- Every First Tier *NMI* and Second Tier *NMI* in the NEM.
- Sample meters for non-NSLP profile calculations and embedded generating units for NSLP calculations.
- Every wholesale connection point in the NEM, including generation, interconnectors and bulk supply points.

4. CATS_METER_REGISTER

The CATS_Meter_Register table is a NMI master table containing data that is stored at the Meter Register level. Information stored at this level includes the NSRD. It is updated whenever a Change Request containing inbound Meter Register data is completed.

Note: References to 'LNSP' include the ENM for *child connection points*.

Table 3 CATS_METER_REGISTER

| Data Element Name | Description | Standing Data Required | Party to Provide |
|--------------------------------|---|------------------------|------------------|
| AdditionalSiteInformation | Free text, descriptive of the Site, describing Site access and the relationship between the <i>metering point</i> and the <i>connection point</i> . | OPTIONAL | MPB |
| AssetManagementPlan | Asset management plan If a Site plan is used, free text description of plan. If a sample plan is used, the name of the AEMO approved plan. | OPTIONAL | MPB |
| CalibrationTables | Calibration tables – details of any calibration factors programmed into the <i>meter</i> . | OPTIONAL | MPB |
| CommunicationsEquipmentType | Used to store baud rate for installed communication equipment in a code, calculated by dividing the baud rate by 100, of the installed communication equipment. For example, 48 = 4800 baud. | OPTIONAL | MPB |
| CommunicationsProtocol | Used to provide details of access through switch units (if installed). Data to include Switch Unit, Dial Pkg, Port#, userid, password. | OPTIONAL | MPB |
| <u>ConnectionConfiguration</u> | <p><u>Two-character code to denote information about the configuration of the connection point.</u></p> <p><u>First Character = Connection Type</u></p> <p><u>H = High voltage (as defined in the NER)</u></p> <p><u>L = Low voltage (lower than the threshold defined for high voltage in the NER)</u></p> <p><u>Second Character = Phases In Use</u></p> <p><u>1 = Single Phase</u></p> <p><u>2 = Two-Phase</u></p> <p><u>3 = Three-Phase</u></p> <p><u>Mandatory where there is an installed meter</u></p> <p><u>Field to be provided by MPB</u></p> | | |

| Data Element Name | Description | Standing Data Required | Party to Provide |
|----------------------------------|---|--|------------------|
| CurrentTransformerLocation | A free text field to indicate the location of the current transformer at the site. | REQUIRED NOT USED for NCONUML, BULK, XBOUNDARY and INTERCON | MPB |
| CurrentTransformerType | Whether the current transformer at the metering installation is single phase or three phase. This value must correspond to a valid Current Transformer Type value in the Valid Transformer Fields values reference table listed in section 11. | REQUIRED NOT USED for NCONUML, BULK, XBOUNDARY and INTERCON | MPB |
| CurrentTransformerRatioAvailable | The available ratio of the current transformer at the metering installation. This value must correspond to a valid Current Transformer Ratio (Available) value in the Valid Transformer Fields values reference table listed in section 11. | REQUIRED NOT USED for NCONUML, BULK, XBOUNDARY and INTERCON | MPB |
| CurrentTransformerRatioConnected | The connected ratio of the current transformer at the metering installation. This value must correspond to a valid Current Transformer Ratio (Connected) value in the Valid Transformer Fields values reference table listed in section 11. | REQUIRED NOT USED for NCONUML, BULK, XBOUNDARY and INTERCON | MPB |
| CurrentTransformerAccuracyClass | The accuracy class of the current transformer at the metering installation. This value must correspond to a valid Current Transformer Accuracy Class value in the Valid Transformer Fields values reference table listed in section 11. | REQUIRED NOT USED for BULK, XBOUNDARY and INTERCON | MPB |
| CurrentTransformerTest | Type of test performed on metering installation with Current Transformer which can be one of the following: <ul style="list-style-type: none"> • Tested (definition – part of 100% testing) • Sample Tested (definition – tested as part of a sample plan) • Sample (definition – part of an approved sample plan) This value must correspond to a valid transformer test value in the Valid Transformer Test Values reference table listed in section 11. | REQUIRED NOT USED for BULK, XBOUNDARY and INTERCON | MPB |
| CurrentTransformerTestDate | A date that represents actual test date for metering installations with Current Transformer tested or date represents family expiry date for those included in an approved sample plan. | REQUIRED NOT USED for BULK, XBOUNDARY and INTERCON | MPB |

STANDING DATA FOR MSATS



| Data Element Name | Description | Standing Data Required | Party to Provide |
|------------------------|---|--|------------------|
| DataConversion | Actual Pulse Multipliers | OPTIONAL | MPB |
| DataValidations | Free text description of required data validations. | OPTIONAL | MPB |
| EstimationInstructions | Estimation instructions. Free text field | OPTIONAL | MPB |
| GPSCoordinatesLat | GPS Coordinates Latitude is the angular measurement North or South of the equator in decimal degrees (up to 7 decimal places). Angles South of the equator will be represented as negative values. E.g. -37.8886755. It is the latitude of the metering installation and not of the site. | <p>For NMI's with manually read meters: REQUIRED for 36 months from effective date of these Procedures, MANDATORY thereafter.</p> <p>For NMI's with remotely read meters: MANDATORY for new NMI's established from the effective date of these Procedures and all NMI's when they have a physical field site visit, REQUIRED for all other NMI's.</p> <p>Not Used for NMIS for Type 7 and NCONUML.</p> | MPB |

| Data Element Name | Description | Standing Data Required | Party to Provide |
|--------------------|--|---|------------------|
| GPSCoordinatesLong | GPS Coordinates Longitude is the angular measurement East or West of the prime meridian in decimal degrees (up to 7 decimal places). Angles East of the Prime Meridian (e.g. Australia) will be represented as positive values. E.g. +145.1410361. It is the longitude of the metering installation and not of the site. | <p>For NMIs with manually read meters: REQUIRED for 36 months from effective date of these Procedures, MANDATORY thereafter.</p> <p>For NMIs with remotely read meters: MANDATORY for new NMIs established from the effective date of these Procedures and all NMIs when they have a physical field site visit, REQUIRED for all other NMIs.</p> <p>Not Used for NMIS for Type 7 and NCONUML.</p> | MPB |
| LastTestDate | The date on which the <i>metering installation</i> was last tested or inspected by the Metering Provider "B". This date will be used if clause 7.9.4(a) of the NER needs to be applied. | REQUIRED | MPB |
| MeasurementType | Code based on the <i>NMI</i> suffix codes, indicating the type of measurements available from the <i>meter</i> . For example, EBQK = bidirectional <i>energy</i> plus reactive Interval Meter. | OPTIONAL NOT USED for types 6 & 7 Transfers. | MPB |
| Constant | The <i>meter</i> K_E (intrinsic constraint of meter in Wh/pulse). | OPTIONAL | MPB |
| Hazard | Free text or code identifying hazards on the site associated with reading, maintaining or installing the <i>meter</i> . If the following are present at the <i>metering installation</i> , they should be listed in this field: Asbestos | REQUIRED | MPB |

STANDING DATA FOR MSATS



| Data Element Name | Description | Standing Data Required | Party to Provide |
|----------------------|---|------------------------|------------------|
| InstallationTypeCode | The Metering Installation Type Code indicates whether the <i>metering installation</i> has to be manually read. This value must correspond to a valid MeterInstallCode in the Meter Installation Codes reference table listed in section 11. | MANDATORY | MPB |
| Location | Free text descriptive material identifying the relationship between the location of the <i>metering point</i> and the <i>connection point</i> . | REQUIRED | MPB |
| Manufacturer | Field to identify the manufacturer of the installed <i>meter</i> . This field will be an enumerated list of values corresponding to current Meter Manufacturers in the industry with the options of UNMETERED and UNKNOWN. | MANDATORY | MPB |
| Model | Field to identify the <i>meter</i> manufacturer's designation for the <i>meter</i> model. This field will be an enumerated list of values corresponding to current Meter Models in the industry with the options of UNMETERED and UNKNOWN. | MANDATORY | MPB |
| Point | Identifies the <i>meter</i> uniquely for the <i>NMI</i> . In the format 0n, where n is the <i>meter</i> number per the protocol described in the NMI Procedure. The allowed values are 01 to 09, 0A to 0H, 0J to 0N, 0P to 0Z. This will allow an audit trail when one <i>meter</i> is removed and a new <i>meter</i> is given the same MeterPoint value. | OPTIONAL | MPB |
| Program | Free text field providing a description of the program used to initialise the installed <i>meter</i> . | OPTIONAL | MPB |

STANDING DATA FOR MSATS



| Data Element Name | Description | Standing Data Required | Party to Provide |
|-------------------|--|------------------------|------------------|
| ReadTypeCode | <p>Code to denote the method and frequency of Meter Reading.</p> <p>First Character = Remote (R) or Manual (M);</p> <p>Second Character = Mode</p> <p>T = telephone</p> <p>W = wireless</p> <p>P = powerline</p> <p>I = infra-red</p> <p>G = galvanic</p> <p>V = visual</p> <p>Third Character = Frequency of Scheduled Meter Readings</p> <p>1 = Twelve times per year</p> <p>2 = Six times per year</p> <p>3 = Four times per year</p> <p>D = Daily or weekly</p> <p>Fourth Character =</p> <ul style="list-style-type: none"> o A – 5 minute o B – 15 minute o C – 30 minute o D – Cannot convert to 5-minute (i.e. due to metering installation de-energised) o M - Manually Read Accumulation Meter <p>For example, MV3M = Manual, Visual, Quarterly, Manually Read Accumulation Meter; RWDC = Remote, Wireless, Daily, 30 minutes interval.</p> | REQUIRED | MPB |
| Route | The route identifier the <i>meter</i> is currently being read in. | OPTIONAL | MPB |

| Data Element Name | Description | Standing Data Required | Party to Provide |
|------------------------|---|---|-------------------------------------|
| SerialNumber | The Meter Serial ID uniquely identifies a <i>meter</i> for a given <i>NMI</i> . Maximum 12 Characters (alpha numeric). Unique for <i>NMI</i> . Use dummy for UMCP (Type 7) and logical (meters). Except for UMCP and logical, SerialNumber should be as displayed on the physical device (also known as property number). SerialNumber to be property number if exists, otherwise the <i>meter</i> manufacturer's serial number, otherwise dummy number. | MANDATORY | MPB |
| Status | A code to denote the status of the <i>meter</i> . This value must correspond to a valid ElectricityMeter/Status in the Meter and RegisterID Codes reference table listed in section 11. | MANDATORY | MPB |
| Use | A code identifying how the <i>meter</i> is used. This value must correspond to a valid Meter Use value in the Valid Meter Use Codes reference table listed in section 11. | MANDATORY | MPB |
| NextScheduledReadDate | Indicates the Scheduled Next Read Date for the <i>meter</i> if a manual Meter Reading is required. | MANDATORY for manually read meters, REQUIRED for Type 7 metering installations with calculated metering data where the forward estimate process is using a BLOCK methodology, and NOT USED for remotely read meters | MPB initially, then MDP for updates |
| NextTestDate | Next date on which the <i>meter</i> should be tested. | OPTIONAL | MPB |
| NMI | <i>NMI</i> . This number is unique for each <i>connection point</i> within the <i>NEM</i> . | MANDATORY | LNSP |
| Password | Read & time set passwords separated by a space. | OPTIONAL | MPB |
| RemotePhoneNumber | The public telephone number to contact a remote Site for <i>metering data</i> . Includes STD prefix and no spaces. | OPTIONAL | MPB |
| TestCalibrationProgram | Test & calibration program. | OPTIONAL | MPB |

| Data Element Name | Description | Standing Data Required | Party to Provide |
|---------------------------------|--|--|------------------|
| TestPerformedBy | Identifying the Metering Provider "B" and the technician responsible for conducting the last test. The technician is to be identified by a number unique to the Metering Provider "B". | OPTIONAL | MPB |
| TestResult | The result from the test performed on the date indicated in the LastTestDate field. This value must correspond to a valid Test Result value in the Valid Test Result Codes reference table listed in section 11. | REQUIRED | MPB |
| TestResultNotes | A statement of compliance indicating the standard of the test regime applied at the time of the last test. | OPTIONAL | MPB |
| TransformerLocation | A free text field to identify the existence of instrument transformers and their location relative to the market connection point. | OPTIONAL | MPB |
| TransformerRatio | A statement of the available and applied <i>transformer</i> ratios. | OPTIONAL | MPB |
| TransformerType | An explanation of the type of <i>transformation</i> used. | OPTIONAL | MPB |
| UserAccessRights | Details of any End User access to the <i>metering installation</i> ; examples include pulse outputs, interface to consumer load management system, or consumer directly accessing data in <i>meter</i> by special agreement. | OPTIONAL | MPB |
| VoltageTransformerLocation | A free text field to indicate the location of the voltage transformer at the site. | REQUIRED NOT USED for NCONUML, BULK, XBOUNDARY and INTERCON | MPB |
| VoltageTransformerType | Whether the voltage transformer at the metering installation is single phase or three phase. This value must correspond to a valid Voltage Transformer Type value in the Valid Transformer Fields values reference table listed in section 11. | REQUIRED NOT USED for NCONUML, BULK, XBOUNDARY and INTERCON | MPB |
| VoltageTransformerRatio | The available or connected ratio of the voltage transformer at the metering installation. This value must correspond to a valid Voltage Transformer Ratio value in the Valid Transformer Fields values reference table listed in section 11. | REQUIRED NOT USED for NCONUML, BULK, XBOUNDARY and INTERCON | MPB |
| VoltageTransformerAccuracyClass | The accuracy class of the voltage transformer at the metering installation. This value must correspond to a valid Voltage Transformer Type value in the Valid Transformer Fields values reference table listed in section 11. | REQUIRED NOT USED for BULK, XBOUNDARY and INTERCON | MPB |

| Data Element Name | Description | Standing Data Required | Party to Provide |
|----------------------------|---|--|-----------------------------------|
| VoltageTransformerTest | Type of test performed on metering installation with Voltage Transformer which can be one of the following: <ul style="list-style-type: none"> • Tested (definition – part of 100% testing) • Sample Tested (definition – tested as part of a sample plan) • Sample (definition – part of an approved sample plan) This value must correspond to a valid transformer test value in the Valid Transformer Test Values reference table listed in section 11. | REQUIRED NOT USED for BULK, XBOUNDRY and INTERCON | MPB |
| VoltageTransformerTestDate | A date that represents actual test date for metering installation with Voltage Transformer tested or date represents family expiry date for those included in an approved sample plan. | REQUIRED NOT USED for BULK, XBOUNDRY and INTERCON | MPB |
| FromDate | Start date of the record. This indicates the date on which the parameters of this particular record apply from. The data applies from the beginning of this date (the start of the day, i.e. 00:00). | MANDATORY | Participant sending transaction |
| ToDate | End date of the record. This indicates the date on which the parameters of this particular record end. The data applies until the end of this date (the end of the day, i.e. 23:59). A default date of 9999-12-31 is recorded if EndDate is not provided. | MANDATORY (Defaults to high date unless supplied) | System generated unless supplied. |
| RowStatus | Indicates whether the record is active or inactive. Whenever a new record is created, it will be A (Active). A change to the data will make this record redundant and its MaintActFlg is changed to I (Inactive). | MANDATORY | System generated |
| MaintenanceDate | Date and time the record was updated. A default date of 9999-12-31 is used when the record is created initially. If the record is subsequently updated, its MaintUpdtDt is changed to the date and time the record was updated. | MANDATORY | System generated |
| CreationDate | Date and time the record was created. | MANDATORY | System generated |

5. CATS_DLF_CODES

The CATS_DLF_Codes table contains a list of DLF Codes and their relevant values. The StartDate and DLFCode fields will need to be provided for *settlements* calculations.

Note: References to 'LNSP' include the ENM for child *connection points*.

Table 4 CATS_DLF_CODES

| Data Element Name | Description | Standing Data Required | Party to Provide |
|-----------------------------------|--|------------------------|------------------|
| DistributionLossFactorCode | A four character alpha-numeric code used to identify DLF values. All <i>NMIs</i> must be assigned a DLF Code. Refer to AEMO Distribution Loss Factor documents for each financial year.. | MANDATORY | AEMO |
| DistributionLossFactorDescription | Description of the DLF Code and value. | MANDATORY | AEMO |
| DistributionLossFactor Value | Numeric value up to 5 decimal places, reflecting the value of the DLF Code. | MANDATORY | AEMO |
| JurisdictionCode | Jurisdiction code to which the <i>NMI</i> belongs. This value must correspond to a valid JurisdictionCode in the Jurisdiction Codes reference table in section 11. | MANDATORY | AEMO |
| RowStatus | Indicates whether the DLF Code is active or inactive. Whenever a new record is created, it will be A (Active). A change to the data will make this record redundant and its MaintActFlg is changed to I (Inactive). | MANDATORY | System generated |
| FromDate | Start date of the record. This indicates the date on which the parameters of this particular record apply from. The data applies from the beginning of this date (the start of the day, i.e. 00:00). | MANDATORY | AEMO |
| ToDate | End date of the record. This indicates the date on which the parameters of this particular record end. The data applies until the end of this date (the end of the day, i.e. 23:59). A default date of 9999-12-31 is recorded if EndDate is not provided. | MANDATORY | System generated |
| MaintenanceDate | Date and time the record was updated. A default date of 9999-12-31 is used when the record is created initially. If the record is subsequently updated, its MaintUpdtDt is changed to the date and time the record was updated. | MANDATORY | System generated |
| CreationDate | Date and time the record was created. | MANDATORY | System generated |

6. CATS_EMB_NET_ID_CODES

The CATS_EMB_NET_ID_CODES table contains embedded network identifier codes, which are used to identify which *embedded network* a NMI belongs to, either as a Parent NMI or a Child NMI.

Note: References to 'LNSP' include the ENM for *child connection points*.

Table 5 CATS_EMB_NET_ID_CODES

| Data Element Name | Description | Standing Data Required | Party to Provide |
|-----------------------------|--|------------------------|------------------|
| EmbeddedNetwork Identifier | Embedded Network Code. Refer to Allocation of Embedded Network Codes for further details. | MANDATORY | AEMO |
| EmbeddedNetwork Description | Description of embedded network identifier. | MANDATORY | AEMO |
| SuburbOrPlaceOrLocality | Locality to which the embedded network identifier belongs. | MANDATORY | AEMO |
| PostCode | Postcode for the locality to which the embedded network identifier belongs. | MANDATORY | AEMO |
| StateOrTerritory | State or Territory abbreviation in accordance with AS 4590. | MANDATORY | AEMO |
| RowStatus | Indicates whether the code is active or inactive. Whenever a new record is created, it will be A (Active). A change to the data will make this record redundant and its MaintActFlg is changed to I (Inactive). | MANDATORY | System generated |
| FromDate | Start date of the record. This indicates the date on which the parameters of this particular record apply from. The data applies from the beginning of this date (the start of the day, i.e. 00:00). | MANDATORY | AEMO |
| ToDate | End date of the record. This indicates the date on which the parameters of this particular record end. The data applies until the end of this date (the end of the day, i.e. 23:59). A default date of 9999-12-31 is recorded if EndDate is not provided. | MANDATORY | System generated |
| MaintenanceDate | Date and time the record was updated. A default date of 9999-12-31 is used when the record is created initially. If the record is subsequently updated, its MaintUpdtDt is changed to the date and time the record was updated. | MANDATORY | System generated |
| CreationDate | Date and time the record was created. | MANDATORY | System generated |

7. CATS_NMI_DATA

The CATS_NMI_DATA table records Master NMI Record data information. It is updated whenever a Change Request containing data in the CATS_INBOUND_NMI_DATA table is completed.

Note: References to 'LNSP' include the ENM for *child connection points*.

Table 6 CATS_NMI_DATA

| Data Element Name | Description | Standing Data Required | Party to Provide |
|--------------------------------------|--|------------------------|------------------|
| NMI | <i>NMI</i> . All alpha characters are Upper Case | MANDATORY | LNSP |
| NMI ClassificationCode | Code used to indicate the NMI Classification Code of this <i>NMI</i> . This value must correspond to a valid NMIClassCode value in the NMI Class Codes reference table listed in section 11. | MANDATORY | LNSP |
| MasterData/ StatusCode | Code used to indicate the status of the <i>NMI</i> . This value must correspond to a valid MasterData/Status value in the NMI Status Codes reference table listed in section 11. | MANDATORY | LNSP |
| TransmissionNode Identifier | This value must correspond to a valid code in the CATS_TNI_Codes table. | MANDATORY | LNSP |
| TransmissionNode Identifier2 | TNI Code assigned, by AEMO, to a distribution network into which energy normally flows through a connection point between adjacent distribution networks that has a single NMI. This value must correspond to a valid code in the CATS_TNI_Codes table. | REQUIRED | AEMO |
| SharedIsolationPointFlag | A flag (Yes, No, Isolated or Unknown) to indicate the Shared Fuse Arrangement for the <i>metering installation</i> . Valid values are Y, N, I or U. This value must correspond to a valid shared isolation point flag value in the Valid Shared Isolation Point Flag Values reference table listed in section 11. | MANDATORY | LNSP |
| MeterMalfunctionExemption Number | The exemption number granted by AEMO when a meter malfunction exemption is granted. | REQUIRED | AEMO |
| MeterMalfunctionExemption ExpiryDate | The end date of the malfunction exemption. | REQUIRED | AEMO |
| JurisdictionCode | Jurisdiction code to which the <i>NMI</i> belongs. This code defines the jurisdictional rules which apply to the transfer of this <i>NMI</i> . This value must correspond to a valid JurisdictionCode value in the Jurisdiction Codes reference table listed in section 11. | MANDATORY | LNSP |
| DistributionLoss FactorCode | Distribution Loss Factor Code. Must be a valid code in the CATS_DLF_Codes table. | MANDATORY | LNSP |
| ConnectionConfiguration | Two character code to denote information about the configuration of the connection point. | MANDATORY | LNSP |

| | | | |
|----------------------------------|--|----------|------|
| | <p>First Character – Connection Type</p> <p>H – High voltage (as defined in the NER)</p> <p>L – Low voltage (lower than the threshold defined for high voltage in the NER)</p> <p>Second Character – Phases In Use</p> <p>1 – Single Phase</p> <p>2 – Two Phase</p> <p>3 – Three Phase</p> | | |
| ChildEmbedded NetworkIdentifier | <p>The embedded network identifier code is used to identify which embedded network this given <i>NMI</i> is the 'child of'. (If on a <i>NMI</i> record this field is not populated, it is assumed the <i>NMI</i> is not the child of any other <i>NMI</i>.)</p> <p>Must be a valid code within the CATS_Emb_Net_ID_Codes table.</p> <p>This field cannot be used unless the Parent <i>NMI</i> has been created and assigned an embedded network identifier code. Refer section 30.4.a of the CATS Procedure.</p> | REQUIRED | LNSP |
| ParentEmbedded NetworkIdentifier | <p>The embedded network identifier code is used to identify which <i>embedded network</i> this given <i>NMI</i> is the 'parent of'. (If on a <i>NMI</i> record this field is not populated, it is assumed the <i>NMI</i> is not the parent of any other <i>NMI</i>.)</p> <p>Must be a valid code within the CATS_Emb_Net_ID_Codes table.</p> | REQUIRED | LNSP |
| BuildingOrProperty Name | A free text description of the full name used to identify the physical building or property as part of its location. | REQUIRED | LNSP |
| LotNumber | The lot reference number allocated to an address prior to street numbering. The word 'LOT' is not required. | REQUIRED | LNSP |
| FlatOrUnitNumber | Specification of the number of the flat or unit which is a separately identifiable portion within a building/complex. | REQUIRED | LNSP |
| FlatOrUnitType | Specification of the type of flat or unit which is a separately identifiable portion within a building/complex. This value must correspond to a valid Flat Type Code, reference AS4590. | REQUIRED | LNSP |
| FloorOrLevelNumber | Floor Number is used to identify the floor or level of a multi-storey building/complex. | REQUIRED | LNSP |
| FloorOrLevelType | Floor Type is used to identify the floor or level of a multi-storey building/complex. This value must correspond to a valid Floor Type Code in the Floor Type Codes, reference AS4590. | REQUIRED | LNSP |
| HouseNumber | The numeric reference of a house or property. Specifically the house number. | REQUIRED | LNSP |
| HouseNumberSuffix | The numeric reference of a house or property. Specifically the single character identifying the house number suffix. | REQUIRED | LNSP |

| | | | |
|-------------------------|---|--|------------------------------|
| HouseNumberTo | The numeric reference of a house or property for scenarios where the address is similar to 4-10 Smith St. For example, HouseNumber = 4 and HouseNumberTo = 10 where the address is 4-10 Smith St. | REQUIRED | LNSP |
| StreetName | Records the thoroughfare name. See notes at end of table for more information on Structured Addresses | REQUIRED | LNSP |
| StreetSuffix | Records street suffixes. This value must correspond to a valid Street Suffix Code, reference AS4590. | REQUIRED | LNSP |
| StreetType | Records the street type abbreviation. This value must correspond to a valid Street Type Code, reference AS4590. | REQUIRED | LNSP |
| SuburbOrPlaceOrLocality | The full name of the general locality containing the specific address. | MANDATORY | LNSP |
| LocationDescriptor | A general field to capture various references to address locations alongside another physical location. | REQUIRED | LNSP |
| PostCode | The descriptor for a postal delivery area, aligned with locality, suburb or place. | MANDATORY | LNSP |
| StateOrTerritory | Defined State or Territory abbreviation. | MANDATORY | LNSP |
| GNAFPID | The Geocoded National Address File (G-NAF) Persistent Identifier (PID) for a given address. | REQUIRED | LNSP/ AEMO |
| SectionNumber | A section number corresponds to a reference that contributes to defining the legal boundaries of a plot of land in NSW and ACT | REQUIRED for NSW and ACT OPTIONAL in all other jurisdictions | LNSP |
| DPNumber | A deposited plan (DP) number corresponds to an image that defines the legal boundaries of a plot of land in NSW and ACT | REQUIRED for NSW and ACT OPTIONAL in all other jurisdictions | LNSP |
| DeliveryPointIdentifier | Delivery point identifier - the numeric descriptor for a postal delivery point which is equal to a physical address. The values are in the range 10000000 – 99999999. | REQUIRED | LNSP/ AEMO |
| AddressLine | To provide the unstructured address (line 1) where a structured address cannot be supplied. | Address Option 2 | LNSP |
| AddressLine | To provide the unstructured address (line 2) where a structured address cannot be supplied. | Address Option 2 | LNSP |
| AddressLine | To provide the unstructured address (line 3) where a structured address cannot be supplied. | Address Option 2 | LNSP |
| Aggregate | This flag determines whether the energy at this <i>connection point</i> is to be treated as consumer <i>load</i> or as | OPTIONAL | (Defaults to 'Y', AEMO |

| | | | |
|--|---|---|-----------------------------------|
| | <p>a <i>generating unit</i> (this may include <i>generator</i> auxiliary loads).</p> <p>MSATS will initially set this field to "Y" This value must correspond to a valid Aggregate value in the Aggregate Codes reference table listed in section 11.</p> | | updates to 'N' as required) |
| FromDate | <p>Start date of the NMI Data record. This indicates the date on which the parameters of this particular NMI data record apply from.</p> <p>The data applies from the beginning of this date (the start of the day, i.e. 00:00).</p> | MANDATORY | LNSP |
| ToDate | <p>End date of the record. This indicates the date on which the parameters of this particular record end. The data applies until the end of this date (the end of the day, i.e. 23:59).</p> <p>A default date of 9999-12-31 is recorded if EndDate is not provided.</p> | MANDATORY (Defaults to high date unless supplied) | System generated unless supplied. |
| RowStatus | <p>Indicates whether the record is active or inactive.</p> <p>Whenever a new record is created, it will be A (Active). A change to the data will make this record redundant and its MaintActFlg is changed to I (Inactive).</p> | MANDATORY | System generated |
| MaintenanceDate | <p>Date and time the record was updated.</p> <p>A default date of 9999-12-31 is used when the record is created initially.</p> <p>If the record is subsequently updated, its MaintUpdtDt is changed to the date and time the record was updated.</p> | MANDATORY | System generated |
| CreationDate | Date and time the record was created. | MANDATORY | System generated |
| Feeder Class | A code to provide Participants with information to indicate the appropriate service level timeframes for performing work in relation to Service Order Requests. | Required in QLD where relevant OPTIONAL in all other jurisdictions | LNSP |
| Customer Classification Code | A code that defines the consumer class as defined in the National Energy Retail Regulations, or in overriding Jurisdictional instruments | MANDATORY | Current FRMP |
| Customer Classification Threshold Code | A code that defines the consumption threshold as defined in the National Energy Retail Regulations, or in overriding Jurisdictional instruments. | MANDATORY | LNSP |

8. CATS_NMI_DATA_STREAM

The CATS_NMI_Data_Stream table is a NMI master table containing data that is stored at the *NMI* Datastream level. Information stored at this level includes suffixes, profile name, average daily load etc. It is updated whenever a Change Request containing inbound Datastream data is completed.

Note: Data is only required for this table if the *NMI* is active in the NEM or is used for profile peel-off in accordance with the Metrology Procedure.

Note: References to 'LNSP' include the ENM for *child connection points*.

Table 7 CATS_NMI_DATA_STREAM

| Data Element Name | Description | Standing Data Required | Party to Provide |
|------------------------------|---|------------------------|------------------|
| NMI | <i>NMI</i> | MANDATORY | MDP LNSP |
| ElectricityDataStream/Suffix | <p>Metering Datastream identifier (for MDM). Identifies the Datastream as delivered to AEMO for settlements purposes.</p> <p>The value must be a valid suffix for this <i>NMI</i> and is active for this date range.</p> <p>The value must comply with requirements of the NMI Procedure.</p> <p>If the MeterInstallCode is COMMSn, MRIM, MRAM, VICAMI or UMCP, the Suffix value must be in the form Nx where DataStreamType is I or P for an interval Datastream. If the MeterInstallCode is BASIC, the Suffix value must be numeric.</p> | MANDATORY | MDP |
| ElectricityDataStream/Status | <p>Code used to indicate the status of the suffix.</p> <p>This value must correspond to a valid StreamStatusCode in the Stream Status Codes reference table listed in section 11.</p> | MANDATORY | MDP |
| AveragedDailyLoad | The <i>energy</i> delivered through a <i>connection point</i> or <i>metering point</i> over an extended period normalised to a "per day" basis (kWh). | MANDATORY | MDP |
| DataStreamType | <p>Indicates the type of data that the the ElectricityDataStream / Suffix is recording.</p> <p>Profile data <i>meters</i> are:</p> <ol style="list-style-type: none"> For registering sample <i>meters</i> used for the calculation of profile shapes where the NMI and Datastream are not used for <i>settlements</i>. For providing external profile shapes into MDM (external PPS). <p>This value must correspond to a valid DataStreamType in the Data Stream Type Codes reference table listed in section 11.</p> | MANDATORY | MDP |
| ProfileName | <p>The Profile Name is a code that identifies the name of the algorithmically derived shape that is used to allocate a Datastream's consumption to TIs. This value must correspond to a valid code in the PROFILE table.</p> <p>For all Interval Meters and sample <i>meters</i>, this must be set to 'NOPROF'.</p> <p>For Accumulation Meters, refer to the MDM Profile for valid profile names.</p> <ul style="list-style-type: none"> In Victoria and the ACT, ProfileName must be NSLP. In NSW, QLD and SA, ProfileName must be NSLP or the relevant controlled load profile. | MANDATORY | MDP |

| | | | |
|-----------------|--|--|-----------------------------------|
| | This value must correspond to a valid ProfileName value in the Profile Codes reference table listed in section 11. | | |
| FromDate | Start date of the <i>NMI</i> data record. This indicates the date on which the parameters of this particular <i>NMI</i> data record apply from. The data applies from the beginning of this date (the start of the day, i.e. 00:00). | MANDATORY | Party sending transaction |
| ToDate | End date of the record. This indicates the date on which the parameters of this particular record end. The data applies until the end of this date (the end of the day, i.e. 23:59). A default date of 9999-12-31 is recorded if EndDate is not provided. | MANDATORY (Defaults to high date unless supplied) | System generated unless supplied. |
| RowStatus | Indicates whether the record is active or inactive. Whenever a new record is created, it will be A (Active). A change to the data will make this record redundant and its MaintActFlg is changed to I (Inactive). | MANDATORY | System generated |
| MaintenanceDate | Date and time the record was updated. A default date of 9999-12-31 is used when the record is created initially. If the record is subsequently updated, its MaintUpdtDt is changed to the date and time the record was updated. | MANDATORY | System generated |
| CreationDate | Date and time the record was created. | MANDATORY | System generated |

9. CATS_REGISTER_IDENTIFIER

The CATS_Register_Identifier table contains data that is stored at the register identifier level. Information stored at this level includes the Network Tariff Code. It is updated whenever a Change Request containing inbound register identifier data is completed.

Note: References to 'LNSP' include the ENM for *child connection points*.

Table 8 CATS_REGISTER_IDENTIFIER

| Data Element Name | Description | Standing Data Required | Party to Provide |
|-------------------|---|------------------------|------------------|
| NMI | <i>NMI</i> . This number is unique for each <i>connection point</i> within the NEM. | MANDATORY | LNSP |
| SerialNumber | The Meter Serial ID uniquely identifies a <i>meter</i> for a given <i>NMI</i> . Maximum 12 Characters (alpha numeric). Unique for <i>NMI</i> . Use dummy for UMCP (Type 7) and logical (<i>meters</i>). Except for UMCP and logical, MeterSerial should be displayed on physical device also known as property number). | MANDATORY | MPB |

| | | | |
|-------------------------------|--|-----------|-----|
| | SerialNumber to be property number if exists, otherwise the <i>meter</i> manufacturers' serial number, otherwise dummy number. | | |
| RegisterID | The RegisterID is used to identify a data source that is obtained from the <i>meter</i> . A single <i>meter</i> may provide multiple data sources. | MANDATORY | MPB |
| NetworkTariffCode | The Network Tariff Code is a free text field required. The text must match the Network Tariff Codes supplied and published by the LNSP. Must be a valid code from the CATS_Network_Tariff_Codes table. | MANDATORY | MPB |
| NetworkAdditional Information | Free text field. | REQUIRED | MPB |
| UnitOfMeasure | Code to identify the unit of measure for data held in this register. | MANDATORY | MPB |
| TimeOfDay | Code to identify the time validity of register contents. As published by each LNSP. This value must correspond to a valid Time of Day value in the Time of Day Codes reference table listed in section 11. For Interval meters, use code "INTERVAL". | MANDATORY | MPB |
| Multiplier | Multiplier required to take a register value and turn it into a value representing billable energy | MANDATORY | MPB |
| DialFormat | Describes the register display format. First number is the number of digits to the left of the decimal place, and the second number is the number of digits to the right of the decimal place. | MANDATORY | MPB |
| Suffix | Metering Datastream identifier (for MDM). Identifies each Datastream at the measurement element level for the <i>connection point</i> identified by the <i>NMI</i> . The value must be a valid suffix for this <i>NMI</i> and is active for this date range. The value must match the value provided in the MDF File. The Suffix value must be unique for each <i>meter</i> . The value must comply with the NMI Procedure For interval data streams, the suffix will indicate the individual data streams contributing to the Nx Suffix value in the CATS_NMI_DataStream table. For basic data streams the value will be identical to the related Suffix value in the CATS_NMI_DataStream table. | MANDATORY | MPB |
| ControlledLoad | Indicates whether the <i>energy</i> recorded by this register is created under a Controlled Load regime ControlledLoad field will have "No" if register does not relate to a Controlled Load. If the register relates to a Controlled Load, it must correspond to a valid Controlled | MANDATORY | MPB |

| | | | |
|---------------------------|--|--|--|
| | Load value in the Controlled Load Codes reference table listed in section 11. | | |
| RegisterDetail/ Status | Lookup code to indicate if register is active. Must ensure that RegisterDetail/Status is not Current (C) when ElectricityMeter/Status is Removed (R). This value must correspond to a valid RegisterDetail/Status from the Meter and RegisterID Codes reference table listed in section 11. | MANDATORY | MPB |
| ConsumptionType | Actual/Subtractive Indicator. Actual (A) implies volume of energy actually metered between two dates. Cumulative (C) indicates a Meter Reading for a specific date. A second Meter Reading is required to determine the consumption between those two Meter Reading dates. For an Interval Meter, ActCumInd = A. This value must correspond to a valid ConsumptionType from the Consumption Type Codes reference table listed in section 11. | MANDATORY | MPB |
| Demand1 | This field contains the peak demand value for summer for network Tariff purposes. Units in kW or kVA | OPTIONAL | MPB (Refers to Network Tariff Code) |
| Demand2 | This field contains an additional demand value (not Summer period). Units in kW or kVA | OPTIONAL | MPB (Refers to Network Tariff Code) |
| FromDate | Start date of the <i>NMI</i> data record. This indicates the date on which the parameters of this particular <i>NMI</i> data record apply from. The data applies from the beginning of this date (the start of the day, i.e. 00:00). | MANDATORY | Participant sending transaction |
| ToDate | End date of the record. This indicates the date on which the parameters of this particular record end. The data applies until the end of this date (the end of the day, i.e. 23:59). A default date of 9999-12-31 is recorded if EndDate is not provided. | MANDATORY (Defaults to high date unless supplied) | System generated unless supplied. |
| RowStatus | Indicates whether the record is active or inactive. Whenever a new record is created, it will be A (Active). A change to the data will make this record redundant and its MaintActFlg is changed to I (Inactive). | MANDATORY | System generated |

| | | | |
|-----------------|---|-----------|------------------|
| MaintenanceDate | Date and time the record was updated. A default date of 9999-12-31 is used when the record is created initially. If the record is subsequently updated, its MaintUpdtDt is changed to the date and time the record was updated. | MANDATORY | System generated |
| CreationDate | Date and time the record was created. | MANDATORY | System generated |

10. CATS_NMI_PARTICIPANT_RELATIONS

The CATS_NMI_Participant_Relations table is a NMI master table containing data that stores the Roles that Participants play for each *NMI*. It is updated whenever a Change Request containing inbound Roles is completed. Each Role record, which contains a single Role code and a single Participant ID, has a start date and an end date, as well as information about when it was created and when it became inactive if it is no longer an active record.

Note: References to 'LNSP' include the ENM for *child connection points*.

Table 9 CATS_NMI_PARTICIPANT_RELATIONS

| Data Element Name | Description | Standing Data Required | Party to Provide |
|-------------------|--|--|-----------------------------------|
| Party | The Participant ID whose relationship (Role) with the <i>NMI</i> is defined in this table. | MANDATORY | LNSP |
| NMI | <i>NMI</i> . This number is unique for each <i>connection point</i> . | MANDATORY | LNSP |
| Role | This defines the relationship (Role) of the Participant with the <i>NMI</i> in this table. | MANDATORY | LNSP |
| FromDate | Start date of the record. This indicates the date on which the parameters of this particular record apply from. The data applies from the beginning of this date (the start of the day, i.e. 00:00). | MANDATORY | Party sending transaction |
| ToDate | End date of the record. This indicates the date on which the parameters of this particular record end. The data applies until the end of this date (the end of the day, i.e. 23:59). A default date of 9999-12-31 is recorded if EndDate is not provided. | MANDATORY (Defaults to high date unless supplied) | System generated unless supplied. |
| RowStatus | Indicates whether the record is active or inactive. Whenever a new record is created, it will be A (Active). A | MANDATORY | System generated |

| | | | |
|-----------------|---|-----------|------------------|
| | change to the data will make this record redundant and its MaintActFlg is changed to I (Inactive). | | |
| MaintenanceDate | Date and time the record was updated. A default date of 9999-12-31 is used when the record is created initially. If the record is subsequently updated, its MaintUpdtDt is changed to the date and time the record was updated. | MANDATORY | System generated |
| CreationDate | Date and time the record was created. | MANDATORY | System generated |

11. REFERENCE TABLES

Table 10 - Valid Aggregate Codes

| Aggregate | Description |
|-----------|---------------|
| Y | Customer load |
| N | Generator NMI |

Table 11 - Valid Consumption Type Codes

| Consumptiontype | Description |
|-----------------|------------------------|
| A | Actual Consumption |
| C | Cumulative Consumption |

Table 12 - Valid Datastream Type Codes

| Datastreamtype | Description |
|----------------|----------------------------|
| I | Interval |
| C | Basic |
| P | Profile Data |
| 1 | Non-Market Active Import |
| 2 | Non-Market Active |
| 3 | Non-Market Reactive Import |
| 4 | Non-Market Reactive |

Table 13 - Valid Profile Codes

| ProfileName | Description |
|-------------|---|
| NSLP | Net System Load Profile. The profile is calculated by MSATS. NSLP represents the system load after all actual <i>interval metering data</i> or specified previously-calculated profiled <i>metering data</i> that is not dependent on the NSLP has been subtracted from a known total system load and represents system-wide usage by consumption-type <i>metering installations</i> . |

| ProfileName | Description |
|-------------|--|
| CLOADNSWCE | Controlled Load profile: Country Energy. (Now Essential Energy) Profile Names beginning with CLOAD are Controlled Load profiles. Controlled Load profiles are applied to Controlled Load Datastreams in NSW. There is one Controlled Load profile for each LNSP area. The names all begin with CLOADNSW to indicate that they are NSW Profile Names followed by two characters to indicate the LNSP area to which it belongs (e.g. EA = EnergyAustralia). |
| CLOADNSWEA | Controlled Load profile: EnergyAustralia (Now Ausgrid). |
| CLOADNSWIE | Controlled Load profile: IntegralEnergy (Now Endeavour Energy) |
| QLDEGXCL31 | Controlled Load profile Energex tariff 31 |
| QLDEGXCL33 | Controlled Load profile Energex tariff 33 |
| SACLOAD | South Australian Controlled Load. |
| NOPROF | Used for interval Datastream types (to indicate that such Datastreams do not need to be profiled to obtain 'readings' for each <i>settlements</i> interval because the data is supplied in 30-minute intervals). |

Table 14 Valid Transformer Fields values

| Transformer Field | Valid Values |
|-------------------|--|
| CT Type | A B C S T U V W LV OTHER HV 1A HV 5A |

| | |
|-------------|-------------------------|
| CT Ratio | 5 : 5 |
| (Available) | 10 : 5 |
| | 15 : 5 |
| | 20 / 50 / 100 / 150 : 5 |
| | 20 / 50 / 100 : 5 |
| | 25 / 50 / 100 / 150 : 5 |
| | 25 / 50 / 100 : 5 |
| | 25 : 5 |
| | 30 : 5 |
| | 40 : 5 |
| | 50 / 100 / 150 : 5 |
| | 50 / 100 : 5 |
| | 50 / 150 / 250 : 5 |
| | 50 / 150 : 5 |
| | 50 : 5 |
| | 60 : 5 |
| | 75 : 5 |
| | 80 : 5 |
| | 100 / 200 / 300 : 5 |
| | 100 / 200 / 400 : 5 |
| | 100 / 200 : 5 |
| | 100 : 5 |
| | 120 : 5 |
| | 125 : 5 |
| | 150 / 300 / 600 : 5 |
| | 150 / 300 : 5 |
| | 150 : 5 |
| | 160 : 5 |
| | 200 / 400 / 800 : 5 |
| | 200 / 400 : 5 |
| | 200 : 5 |
| | 250 : 5 |
| | 300 / 600 : 5 |
| | 300 : 5 |
| | 400 / 800 / 1200 : 5 |
| | 400 : 5 |
| | 500 / 1000 : 5 |
| | 500 : 5 |
| | 600 / 900 / 1200 : 5 |
| | 600 / 1200 : 5 |
| | 600 : 5 |
| | 630 : 5 |
| | 750 / 1500 : 5 |
| | 750 : 5 |
| | 800 / 1200 : 5 |

| |
|-----------------------------------|
| 800 : 5 |
| 1000 / 1500 : 5 |
| 1000 / 2000 / 3000 : 5 |
| 1000 : 5 |
| 1200 : 5 |
| 1250 : 5 |
| 1500 : 5 |
| 1600 : 5 |
| 2000 / 3000 : 5 |
| 2000 : 5 |
| 2400 : 5 |
| 2500 : 5 |
| 3150 : 5 |
| 3200 : 5 |
| 4000 : 5 |
| 4500 : 5 |
| 5000 : 5 |
| 1 : 1 |
| 5 : 1 |
| 25 : 1 |
| 40 / 60 : 1 |
| 50 / 100 / 150 : 1 |
| 50 / 300 : 1 |
| 50 : 1 |
| 75 : 1 |
| 100 / 200 : 1 |
| 100 / 400 / 800 / 1200 : 1 |
| 100 : 1 |
| 125 / 200 : 1 |
| 125 : 1 |
| 150 / 300 / 600 / 800 : 1 |
| 150 / 300 / 600 / 1200 : 1 |
| 150 : 1 |
| 150 : 1 |
| 200 / 400 / 600 : 1 |
| 200 / 400 / 800 / 1200 / 2400 : 1 |
| 200 / 400 / 800 : 1 |
| 200 / 800 / 1200 / 2000 : 1 |
| 200 / 800 / 1200 / 2400 : 1 |
| 200 : 1 |
| 250 / 500 / 1000 : 1 |
| 250 : 1 |
| 300 / 600 / 1200 : 1 |
| 300 : 1 |
| 400 / 800 / 1200 : 1 |

| Transformer Field | Valid Values |
|-------------------|------------------------------|
| | 400 / 800 / 1600 / 2800 : 1 |
| | 400 / 800 / 1600 : 1 |
| | 400 / 800 : 1 |
| | 400 / 1000 / 1200 : 1 |
| | 400 / 1200 : 1 |
| | 400 / 1600 / 2400 : 1 |
| | 500 / 1500 / 2500 : 1 |
| | 500 / 1500 : 1 |
| | 500 : 1 |
| | 600 / 800 / 1200 / 1600 : 1 |
| | 600 / 1200 / 2400 : 1 |
| | 600 : 1 |
| | 630 : 1 |
| | 650 : 1 |
| | 750 : 1 |
| | 800 / 1200 / 2500 : 1 |
| | 800 / 2000 / 2400 / 4000 : 1 |
| | 800 : 1 |
| | 900 : 1 |
| | 1000 / 1600 : 1 |
| | 1000 : 1 |
| | 1100 : 1 |
| | 1200 / 1600 / 2000 : 1 |
| | 1200 : 1 |
| | 1250 : 1 |
| | 1400 : 1 |
| | 1500 / 2000 / 2500 : 1 |
| | 1500 : 1 |
| | 1600 : 1 |
| | 1700 : 1 |
| | 1900 : 1 |
| | 2000 : 1 |
| | 2400 : 1 |
| | 2500 : 1 |
| | 3000 : 1 |
| | 3200 : 1 |
| | 4000 : 1 |
| | 4500 : 1 |
| | 4800 : 1 |
| | 5000 : 1 |

| | |
|-------------------------|----------|
| CT Ratio (Connected) | 5 : 5 |
| | 10 : 5 |
| | 15 : 5 |
| | 20 : 5 |
| | 25 : 5 |
| | 30 : 5 |
| | 40 : 5 |
| | 50 : 5 |
| | 60 : 5 |
| | 75 : 5 |
| | 80 : 5 |
| | 100 : 5 |
| | 120 : 5 |
| | 125 : 5 |
| | 150 : 5 |
| | 160 : 5 |
| | 200 : 5 |
| | 250 : 5 |
| | 300 : 5 |
| | 400 : 5 |
| | 500 : 5 |
| | 600 : 5 |
| | 630 : 5 |
| | 750 : 5 |
| | 800 : 5 |
| | 1000 : 5 |
| | 1200 : 5 |
| | 1250 : 5 |
| | 1500 : 5 |
| | 1600 : 5 |
| | 2000 : 5 |
| | 2400 : 5 |
| | 2500 : 5 |
| | 3150 : 5 |
| | 3200 : 5 |
| | 4000 : 5 |
| | 4500 : 5 |
| | 5000 : 5 |
| | 5 : 1 |
| | 25 : 1 |
| | 40 : 1 |
| | 50 : 1 |
| | 75 : 1 |
| | 100 : 1 |
| | 125 : 1 |

| Transformer Field | Valid Values |
|-------------------|--------------|
| | 150 : 1 |
| | 200 : 1 |
| | 250 : 1 |
| | 300 : 1 |
| | 400 : 1 |
| | 500 : 1 |
| | 600 : 1 |
| | 630 : 1 |
| | 650 : 1 |
| | 750 : 1 |
| | 800 : 1 |
| | 900 : 1 |
| | 1000 : 1 |
| | 1100 : 1 |
| | 1200 : 1 |
| | 1250 : 1 |
| | 1400 : 1 |
| | 1500 : 1 |
| | 1600 : 1 |
| | 1700 : 1 |
| | 1900 : 1 |
| | 2000 : 1 |
| | 2400 : 1 |
| | 2500 : 1 |
| | 3000 : 1 |
| | 3200 : 1 |
| | 4000 : 1 |
| | 4500 : 1 |
| | 4800 : 1 |
| | 5000 : 1 |

| Transformer Field | Valid Values |
|------------------------------------|--|
| CT Accuracy Class | 0.1 0.2 0.2M 0.2ME1.5 0.2ME2 0.2ME2.5 0.2S 0.5 0.5M 0.5ME1.25 0.5ME2 0.5ME2.5 0.5 EXT 200% 0.5S 0.5S EXT 200% 1 2 AM BM 0.05PX UNKNOWN |
| VT Type | IVT (Inductive Voltage Transformer) CVT (Capacitive Voltage Transformer) COMBINED (IVT + CT) Three-Phase Three-Limb Three-Phase Five-Limb |
| VT Ratio (Available and Connected) | 3300 : 110 5000 : 110 5500 : 110 6600 : 110 11000 : 110 11500 : 110 22000 : 110 33000 : 110 44000 : 110 66000 : 110 110000 : 110 132000 : 110 220000 : 110 275000 : 110 330000 : 110 500000 : 110 |

| Transformer Field | Valid Values |
|-------------------|--|
| VT Accuracy Class | 0.01M 0.2M 0.5M 1M A B C D AL BL UNKNOWN |

Table 15 Valid Meter Use Codes

| MeterUse | Description |
|-------------|----------------------------------|
| REVENUE | Revenue meter or Unmetered load. |
| CHECK | Check meter. |
| STATISTICAL | Statistical meter. |
| TUOS | TUOS meter. |
| LOGICAL | Logical meter. |
| SAMPLE | Sample meter. |
| AVERAGE | Average meter. |
| PREPAID | Prepaid meter. |
| INFORMATION | Information meter. |
| UNKNOWN | Unknown meter use code. |

Table 16 Valid Time of Day Codes

| TimeOfDay | Description |
|------------|--|
| ALLDAY | All day |
| INTERVAL | Interval time of day, used for all Interval metering |
| PEAK | Peak time of day |
| BUSINESS | Business time of day |
| SHOULDER | Shoulder time of day |
| EVENING | Evening time of day |
| OFFPEAK | Off peak time of day |
| CONTROLLED | Controlled time of day |
| DEMAND | Demand is used for describing a register |

Table 17 Valid Controlled Load Codes

| ControlledLoad | Description |
|----------------|--|
| No | This register does not record controlled load. |
| CL1 | Controlled load 1 |
| CL2 | Controlled load 2 |
| CL3 | Controlled load 3 |

Table 18 Valid Test Result Codes

| TestResult | Description |
|------------|-----------------|
| PASS | Test has passed |
| FAIL | Test has failed |

Table 19 Valid Transformer Test Values

| TestResult | Description |
|---------------|---------------------------------|
| Tested | Part of 100% testing |
| Sample Tested | Tested as part of a sample plan |
| Sample | Part of an approved sample plan |

Table 20 Valid Shared Isolation Point Flag Values

| SharedIsolationPointFlag | Description |
|--------------------------|---|
| Y | Indicates that a Shared Fuse Arrangement is present |
| N | Indicates that no Shared Fuse Arrangement is present |
| I | Indicates the metering installation is Isolated independently but still part of a Shared Fuse Arrangement |
| U | Indicates that the presence of a Shared Fuse Arrangement is Unknown |

Note: Refer to the MSATS CATS Procedure section 4 for details on the valid codes for the following:

- Jurisdiction Codes
- Metering Installation Type Codes
- NMI Classification Codes
- NMI Status Codes
- Datastream Status Codes

12. USE OF NMI SUFFIX TO POPULATE CATS_REGISTER_IDENTIFIER

For any particular *connection point* there may be multiple energy measurement elements and data recorders with multiple channels. Accurate identification of Datastreams is essential. The NMI Procedure includes the requirements for the use of a suffix to the *NMI* that identifies these Datastreams. The *DataStreamSuffix* detailed in the NMI Procedure provides identification at the measurement element level for all Datastreams from the *connection point* identified by the *NMI*. The *DataStreamSuffix* is commonly known as the *NMISuffix*. The *NMISuffix* is labelled as 'Suffix' in the Browser and is the *ElectricityDataStream/Suffix* data element in *aseXML*.

The *NMISuffix* was first used in the NMI Procedure to describe, in conjunction with the *NMI*, the data transferred from the MDP to AEMO and Participants for *settlements*. The *NMISuffix* was further extended to describe Datastreams in MSATS, and numeric suffixes were developed to describe the data from type 6 *metering installations*.

In MSATS, the *NMISuffix* is used in the *CATS_NMI_DATA_STREAM* table to describe the data as delivered to AEMO. For *settlements* purposes this data must be 'NET' [Export from *network*, less import to *network*] and will be 'Nx' for an interval Datastream, or numeric for an Accumulation Meter.

In MSATS release 2.0 a new table, *CATS_REGISTER_IDENTIFIER*, was introduced to link identifiers for the source *meter* register(s) to the Datastream suffix in the *CATS_NMI_DATA_STREAM* table. The purpose of the table is to enable the alignment of the data held in MSATS and the data being transferred between Participants in the B2B process.

This link is achieved through the *RegisterID* (which describes the data source at the *metering installation*) and *ElectricityDataStream/Suffix* (which describes the *NMISuffix* to which the *RegisterID* contributes) data elements. This is a many-to-one relationship, i.e. there may be multiple *RegisterID* values for each *ElectricityDataStream/Suffix* value in the *CATS_REGISTER_IDENTIFIER* table.

- The *RegisterID* identifies the measurement element and type of measurement for an Interval Meter, and identifies the location of a stored energy value in an Accumulation Meter.
- The *ElectricityDataStream/Suffix* value in the *CATS_NMI_DATA_STREAM* table identifies the Datastream registered in MSATS. For *settlements* purposes, Interval Meter Datastreams will be the NET suffix (format Nx) and for Accumulation Meter Datastreams the suffix value is numeric. MSATS requires data to be delivered against this suffix (if the Datastream is ACTIVE). MSATS does not validate the values entered in this field.
- The *ElectricityDataStream/Suffix* value in the *CATS_REGISTER_IDENTIFIER* table identifies the individual Datastream(s) contributing to the *ElectricityDataStream/Suffix* value in the *CATS_NMI_DATA_STREAM* table. For interval Datastreams, the suffix(es) will indicate the individual Datastream(s) contributing to the Nx Suffix value in the *CATS_NMI_DATA_STREAM* table where the *DataStreamType* is P or I (Refer section 14 for examples). For accumulation Datastreams the value will be numeric and will be identical to the related Suffix value in the *CATS_NMI_DATA_STREAM* table (refer section 13 for examples).
- The *ElectricityDataStream/Suffix* values used in the *CATS_REGISTER_IDENTIFIER* table are used to identify *metering data* contained in MDFF Files (in the *NMISuffix* field).
- The linkage between the *RegisterID* and *ElectricityDataStream/Suffix* exists because the *ElectricityDataStream/Suffix* data element is populated in the *CATS_REGISTER_IDENTIFIER* table.

- The RegisterID data element has no standard format; therefore, the MPB must determine the appropriate population of this field, e.g. it may be used to indicate the programming code of the register.

There is an inconsistent understanding across industry of the meaning of the terms 'register' and 'datastream'. Conventionally, to field metering personnel, a 'register' contains a single value, while a 'datastream' represents an array of time separated register values in chronological order.

For Accumulation Meters, the RegisterID refers to the non-volatile storage of the cumulative energy register(s). The RegisterID will have identification with the displays of the *meters*, or identification of internal data stores.

For Accumulation Meters, the ElectricityDataStream/Suffix data element in the CATS_REGISTER_IDENTIFIER table may have a many-to-one relationship with the ElectricityDataStream/Suffix data element in the CATS_NMI_DATA_STREAM table. That is, the same Suffix may occur several times in the CATS_REGISTER_IDENTIFIER table and occur once only in the CATS_NMI_DATA_STREAM table.

For Interval Meters, the definition of the RegisterID field is less obvious. To make this field useful, the RegisterID should be associated with the ElectricityDataStream/Suffix. As Interval Meters may have multiple measurement elements and there may be multiple *meters* for a *NMI*, the MDP must manage Datastreams against a *NMI* to avoid duplication of ElectricityDataStream/Suffixes and provide correct mapping of RegisterIDs.

13. ASSIGNMENT OF DATA – ACCUMULATION METERS

This section details examples of the assignment of data for various basic *metering installations*. For Accumulation Meters, the Suffix values in CATS_REGISTER_IDENTIFIER and CATS_NMI_DATA_STREAM tables are always numeric.

13.1. Single Meter, no controlled load

A Accumulation Meter with a single register measuring a Non-Controlled Load will have a single Datastream suffix 11 for the *NMI*.

Table 21 Example CATS_NMI_DATA_STREAM

| Data Element: | NMI | Suffix | ElectricityDataStream/Status |
|---------------|------------|--------|------------------------------|
| Value | 0123456789 | 11 | A |

The CATS_REGISTER_IDENTIFIER table indicates that the *meter* has only one register. The Suffix in the CATS_REGISTER_IDENTIFIER '11' denotes that data from RegisterID 01 contributes to the Datastream identified by Suffix 11 in CATS_NMI_DATA_STREAM

Table 22 Example CATS_REGISTER_IDENTIFIER

| Data Element: | Serial Number | RegisterID | UnitOfMeasure | TimeOfDay | Suffix | Controlled Load |
|---------------|---------------|------------|---------------|-----------|--------|-----------------|
| Value | ABCD1111 | 01 | KWH | ALLDAY | 11 | No |

The Suffix in CATS_NMI_DATA_STREAM will be recorded as '11' by the MDP and the Suffix in CATS_REGISTER_IDENTIFIER must then be '11'.

13.2. Two Single Element Meters, no controlled load

The *NMI* has two Accumulation Meters, each *meter* with single register. The data from the two *meters* will be submitted to MSATS as two Datastreams.

Table 23 Example CATS_NMI_DATA_STREAM

| Data Element: | NMI | Suffix | ElectricityDataStream/Status |
|---------------|------------|--------|------------------------------|
| Values | 0123456789 | 11 | A |
| | 0123456789 | 12 | A |

Table 24 Example CATS_REGISTER_IDENTIFIER

| Data Element: | Serial Number | RegisterID | UnitOfMeasure | TimeOfDay | Suffix | Controlled Load |
|---------------|---------------|------------|---------------|-----------|--------|-----------------|
| Values | ABCD1111 | 01 | KWH | ALLDAY | 11 | No |
| | XYZA1112 | 01 | KWH | ALLDAY | 12 | No |

13.3. Two Single Element Meters, one with controlled load

A *NMI* has two Accumulation Meters, each *meter* has a single register, and one *meter* is measuring a Controlled Load. The data from the two *meters* is submitted to MSATS as two Datastreams.

Table 25 Example CATS_NMI_DATA_STREAM

| Data Element: | NMI | Suffix | ElectricityDataStream/Status |
|---------------|------------|--------|------------------------------|
| Value | 0123456789 | 11 | A |
| | 0123456789 | 42 | A |

Table 26 Example CATS_REGISTER_IDENTIFIER

| Data Element: | Serial Number | RegisterID | UnitOfMeasure | TimeOfDay | Suffix | Controlled Load |
|---------------|---------------|------------|---------------|------------|--------|-----------------|
| Values | ABCD1111 | 01 | KWH | ALLDAY | 11 | No |
| | XYZA1112 | 01 | KWH | CONTROLLED | 42 | CL1 |

13.4. One Meter with Two Registers, one measuring a controlled load

NMI has one Accumulation Meter with two registers. The second register is measuring a Controlled Load.

Table 27 Example CATS_NMI_DATA_STREAM

| Data Element: | NMI | Suffix | ElectricityDataStream/Status |
|---------------|------------|--------|------------------------------|
| Value | 0123456789 | 11 | A |
| | 0123456789 | 42 | A |

Table 28 Example CATS_REGISTER_IDENTIFIER

| Data Element: | Serial Number | RegisterID | UnitOfMeasure | TimeOfDay | Suffix | Controlled Load |
|---------------|---------------|------------|---------------|-----------|--------|-----------------|
| Value | ABCD1111 | 01 | KWH | PEAK | 11 | No |

| Data Element: | Serial Number | RegisterID | UnitOfMeasure | TimeOfDay | Suffix | Controlled Load |
|---------------|---------------|------------|---------------|------------|--------|-----------------|
| | ABCD1111 | 02 | KWH | CONTROLLED | 41 | CL3 |

13.5. Single Multi-function Meter

Accumulation Meter has 4 registers, one register being a Controlled Load.

Table 29 Example CATS_NMI_DATA_STREAM

| Data Element: | NMI | Suffix | ElectricityDataStream/Status |
|---------------|------------|--------|------------------------------|
| Values | 0123456789 | 11 | A |
| | 0123456789 | 21 | I |
| | 0123456789 | 31 | A |
| | 0123456789 | 41 | A |

Each register is separately identified in CATS_NMI_Data_Stream. However, register 2 on *meter* 1 is inactive in MSATS, and therefore data is not accepted by MSATS for this Suffix.

Table 30 Example CATS_REGISTER_IDENTIFIER

| Data Element: | Serial Number | RegisterID | UnitOfMeasure | TimeOfDay | Suffix | Controlled Load |
|---------------|---------------|------------|---------------|------------|--------|-----------------|
| Values | ABCD1111 | 01 | KWH | PEAK | 11 | No |
| | ABCD1111 | 02 | KWH | SHOULDER | 21 | No |
| | ABCD1111 | 03 | KWH | OFFPEAK | 31 | No |
| | ABCD1111 | 04 | KWH | CONTROLLED | 41 | CL3 |

Note: The *meter* may have register identification and therefore these numbers can be used in the table as RegisterID.

13.6. Two meters, three registers. One register measures a controlled load

Table 31 Example CATS_NMI_DATA_STREAM

| Data Element: | NMI | Suffix | ElectricityDataStream/Status |
|---------------|------------|--------|------------------------------|
| Values | 0123456789 | 11 | A |
| | 0123456789 | 21 | A |
| | 0123456789 | 42 | A |

Table 32 Example CATS_REGISTER_IDENTIFIER

| Data Element: | Serial Number | RegisterID | UnitOfMeasure | TimeOfDay | Suffix | Controlled Load |
|---------------|---------------|------------|---------------|-----------|--------|-----------------|
| Values | ABCD1111 | 01 | KWH | PEAK | 11 | No |
| | ABCD1111 | 02 | KWH | OFFPAK | 21 | No |

| Data Element: | Serial Number | RegisterID | UnitOfMeasure | TimeOfDay | Suffix | Controlled Load |
|---------------|---------------|------------|---------------|------------|--------|-----------------|
| | XYZA1112 | 01 | KWH | CONTROLLED | 42 | CL2 |

14. ASSIGNMENT OF DATA – INTERVAL METERS

This section details examples of the assignment of data for various Interval Meters.

14.1. One meter

Table 33 Example CATS_NMI_DATA_STREAM

| Data Element: | NMI | Suffix | ElectricityDataStream/Status |
|---------------|------------|--------|------------------------------|
| Value | 0123456789 | N1 | A |

The CATS_Register_Identifier table indicates that the *meter* has only one register. The Suffix in the CATS_REGISTER_IDENTIFIER [E1] denotes that data from RegisterID 01 contributes to the Datastream identified by Suffix N1 in the CATS_NMI_DATA_STREAM table.

Table 34 Example CATS_REGISTER_IDENTIFIER

| Data Element: | Serial Number | RegisterID | UnitOfMeasure | TimeOfDay | Suffix |
|---------------|---------------|------------|---------------|-----------|--------|
| Value | ABCD1111 | 01 | KWH | INTERVAL | E1 |

E1 indicates that it is a single element measuring export.

14.2. Import/Export meter

Interval Meter has a two registers, registering import and export *energy*. A single Datastream suffix N1 is defined for the *NMI* indicating a netting-off of export less import Datastreams for this *connection point*.

Table 35 Example CATS_NMI_DATA_STREAM

| Data Element: | NMI | Suffix | ElectricityDataStream/Status |
|---------------|------------|--------|------------------------------|
| Value | 0123456789 | N1 | A |

The CATS_REGISTER_IDENTIFIER table indicates that the *meter* has two registers, one for IMPORT and one for EXPORT.

Table 36 Example CATS_REGISTER_IDENTIFIER

| Data Element: | Serial Number | RegisterID | UnitOfMeasure | TimeOfDay | Suffix |
|---------------|---------------|------------|---------------|-----------|--------|
| Values | ABCD1111 | E1 | KWH | INTERVAL | E1 |
| | ABCD1111 | B1 | KWH | INTERVAL | B1 |

Only one RegisterID with the Suffix 'E1' permitted per *meter* in CATS_REGISTER_IDENTIFIER.

Only one RegisterID with the Suffix 'B1' permitted per *meter* in CATS_REGISTER_IDENTIFIER.

The energy volumes for the Suffix 'N1' in CATS_NMI_DATA_STREAM are calculated by $N1 = E1 - B1$.

The Suffixes in the CATS_REGISTER_IDENTIFIER denote that data from RegisterIDs 'E1' and 'B1' contribute to the Datastream identified by Suffix 'N1' in CATS_NMI_DATA_STREAM. That is, the Datastreams 'E1' and 'B1' supplied by the MDP to the FRMP for this meter have contributed to the Datastream N1 in MSATS.

14.3. One meter: multiple registers

Interval Meter has a single measurement element registering import and export *energy*, reactive and *voltage*. A single Datastream Suffix 'N1' is defined for the *NMI* indicating netting-off of all *energy* Datastreams for this *connection point*.

Table 37 Example CATS_NMI_DATA_STREAM

| Data Element: | NMI | Suffix | ElectricityDataStream/Status |
|---------------|------------|--------|------------------------------|
| Value | 0123456789 | N1 | A |

The CATS_Register_Identifier table indicates that the *meter* has five registers: two for IMPORT of *energy* and reactive; two for EXPORT of *energy* and reactive; and one for *voltage* monitoring. The Suffixes in the CATS_REGISTER_IDENTIFIER 'N1' denote that data from RegisterID 'E1' and 'B1' contribute to the Datastream identified by suffix N1 in CATS_NMI_DATA_STREAM.

Table 38 Example CATS_REGISTER_IDENTIFIER

| Data Element: | Serial Number | RegisterID | UnitOfMeasure | TimeOfDay | Suffix |
|---------------|---------------|------------|---------------|-----------|--------|
| Values | ABCD1111 | E1 | KWH | AINTERVAL | E1 |
| | ABCD1111 | B1 | KWH | INTERVAL | B1 |
| | ABCD1111 | Q1 | KVARH | INTERVAL | Q1 |
| | ABCD1111 | K1 | KVARH | INTERVAL | K1 |
| | ABCD1111 | V1 | VOLTS | INTERVAL | V1 |

The energy volumes for the Suffix 'N1' is calculated by $NET (E1 - B1)$.

14.4. One meter: Twin Measurement Elements

Certain multifunction *meters* have the capability for initial installation as an Accumulation Meter, but can be re-programmed to provide *interval metering data*.

The NER do not permit the use of two different types of *metering installation* on the one *NMI*, and therefore these two *metering* functions MUST NOT be active simultaneously in MSATS. The MDP and RP will be held accountable for a breach of this requirement.

The CATS_REGISTER_IDENTIFIER can be used to record the *meter* capability.

If this *meter* were configured as an Accumulation Meter in MSATS, the configuration might be as shown in the Tables 32 & 33.

Table 39 Example CATS_NMI_DATA_STREAM

| Data Element: | NMI | Suffix | ElectricityDataStream/Status |
|---------------|------------|--------|------------------------------|
| Values | 0123456789 | N1 | I |

| Data Element: | NMI | Suffix | ElectricityDataStream/Status |
|---------------|------------|--------|------------------------------|
| | 0123456789 | N2 | I |
| | 0123456789 | 11 | A |
| | 0123456789 | 21 | A |
| | 0123456789 | 31 | A |
| | 0123456789 | 41 | A |

Table 40 Example CATS_REGISTER_IDENTIFIER

| Data Element: | Serial Number | RegisterID | UnitOfMeasure | TimeOfDay | Suffix |
|---------------|---------------|------------|---------------|-----------|--------|
| Values | AB888888 | E1 | KWH | INTERVAL | null |
| | AB888888 | E2 | KWH | INTERVAL | null |
| | AB888888 | 25 | KWH | PEAK | 11 |
| | AB888888 | 26 | KWH | SHOULDER | 21 |
| | AB888888 | 35 | KWH | OFFPEAK | 31 |
| | AB888888 | 36 | KWH | CL1 | 41 |

The CATS_REGISTER_IDENTIFIER table values for this *meter* when it is operated as an Interval Meter are shown below. The RegisterID for the Accumulation Meter registers in this type of *meter* are user defined. The Interval Meter suffixes must be added to the *NMI* and made active, and the basic Suffixes made inactive at the same date.

Table 41 Example CATS_NMI_DATA_STREAM

| Data Element: | NMI | Suffix | ElectricityDataStream/Status |
|---------------|------------|--------|------------------------------|
| Values | 0123456789 | N1 | A |
| | 0123456789 | N2 | A |
| | 0123456789 | 11 | I |
| | 0123456789 | 21 | I |
| | 0123456789 | 31 | I |
| | 0123456789 | 41 | I |

Table 42 Example CATS_REGISTER_IDENTIFIER

| Data Element: | Serial Number | RegisterID | UnitOfMeasure | TimeOfDay | Suffix |
|---------------|---------------|------------|---------------|-----------|--------|
| Values | AB888888 | E1 | KWH | INTERVAL | E1 |
| | AB888888 | E2 | KWH | INTERVAL | E2 |
| | AB888888 | 25 | KWH | PEAK | null |
| | AB888888 | 26 | KWH | OFFPEAK | null |
| | AB888888 | 35 | KWH | PEAK | null |
| | AB888888 | 36 | KWH | OFFPEAK | null |

If a second *meter* of the same configuration were established on this *NMI* 'E3' and 'E4' would be required for the Datastreams to provide MDPs and *retailers* with unambiguous identification of Datastreams.

15. ASSIGNMENTS OF DATA – SAMPLE METERS

The application of profiles in accordance with the Metrology Procedure requires *interval metering data* from Sites that have Accumulation Metering. However, the NER do not permit different metering installation types on the one *NMI*, and in any case, the Participants associated with the *interval metering data* are different to those associated with the Accumulation Meter. Therefore, for these *connection points*, two different *NMIs* are used.

There are *meters* that can combine the required Accumulation Metering and Interval Metering functions. An example is shown below.

15.1. Multifunction Sample Meter

In this case, a single *meter* is registered within MSATS for two purposes against two *NMIs*. This is a special case, and should not be used other than for this non-standard purpose. The *meter* has two circuits, with Accumulation Metering for *energy* trading and Interval Metering for the sample profile.

In this example, *NMI* 9801234567 is associated with the sample *meter installation* and *NMI* 9876543210 with the End User installation.

Table 43 Example CATS_NMI_DATA_STREAM

| Data Element: | NMI | Suffix | ElectricityDataStream/Status | DataStreamType |
|---------------|------------|--------|------------------------------|----------------|
| Values | 9801234567 | N1 | A | P |
| | 9876543210 | 11 | I | C |
| | 9876543210 | 12 | I | C |
| | 9876543210 | 41 | A | C |

Table 44 Example CATS_REGISTER_IDENTIFIER

| Data Element: | NMI | MeterSerial | RegisterID | UnitOfMeasure | TimeOfDay | Suffix |
|---------------|------------|-------------|------------|---------------|-----------|--------|
| Values | 9801234567 | AB888888 | E1 | KWH | INTERVAL | E1 |
| | 9876543210 | AB888888 | 11 | KWH | PEAK | null |
| | 9876543210 | AB888888 | 12 | KWH | OFFPEAK | null |
| | 9876543210 | AB888888 | 41 | KWH | CL1 | 41 |

Note: Suffix '11/12' have a Status of 'I' for 1st Tier and 'A' for 2nd Tier.

First tier *metering data* is not required for AEMO to settle the *market*.

Controlled Load data for first tier and second tier is required by AEMO to settle the *market*.

In this example, once the End User's Site becomes a Tier 2 Site, all three basic Datastreams need to become active (StreamStatusCode = A).

16. CROSS REFERENCE OF BROWSER AND ASEXML DATA ELEMENTS

The tables below list the names that are used in the MSATS browser for each of the MSATS tables detailed in sections 4 to 10. The table also provides the aseXML data element names and the respective formats used in each context.

In some cases, such as date fields, the format of the field is shown differently in the Browser to that used in the related aseXML transactions. Also, aseXML uses full words throughout, rather than the coded values used in the Browser.

Refer section 17 for examples of the typical data element values as shown in the Browser. Section 18 provides definitions of the Browser formats shown in this section.

Table 45 CATS_Meter_Register

| Browser Field Name | aseXML Data Element Name | aseXML Path | Browser Format | aseXML Data Type |
|------------------------------------|---------------------------------|---|----------------|----------------------------|
| Additional Site Information | AdditionalSiteInformation | ElectricityMeter/AdditionalSiteInformation | VARCHAR2(100) | xsd:string maxLen = 100 |
| Asset Management Plan | AssetManagementPlan | ElectricityMeter/AssetManagementPlan | VARCHAR2(50) | xsd:string maxLen = 50 |
| Calibration Tables | CalibrationTables | ElectricityMeter/CalibrationTables | VARCHAR2(50) | xsd:string maxLen = 50 |
| Communication Equipment Type | CommunicationsEquipmentType | ElectricityMeter/CommunicationsEquipmentType | VARCHAR2(4) | xsd:string maxLen = 4 |
| Communication Protocol | CommunicationsProtocol | ElectricityMeter/CommunicationsProtocol | VARCHAR2(50) | xsd:string maxLen = 50 |
| Current Transformer Location | CurrentTransformerLocation | ElectricityMeter/CurrentTransformerLocation | VARCHAR(50) | xsd:string maxLen = 50 |
| Current Transformer Type | CurrentTransformerType | ElectricityMeter/CurrentTransformerType | VARCHAR(20) | xsd:string maxLen = 20 |
| Current Transformer RatioAvailable | CurrentTransformerRatio | ElectricityMeter/CurrentTransformerRatioAvailable | VARCHAR(50) | xsd:string maxLen = 50 |
| Current Transformer RatioConnected | CurrentTransformerRatio | ElectricityMeter/CurrentTransformerRatioConnected | VARCHAR(20) | xsd:string maxLen = 20 |
| Current Transformer Accuracy Class | CurrentTransformerAccuracyClass | ElectricityMeter/CurrentTransformerAccuracyClass | VARCHAR(50) | xsd:string maxLen = 50 |
| Current Transformer Test | CurrentTransformerTest | ElectricityMeter/CurrentTransformerTest | VARCHAR2(20) | xsd:string maxLen = 20 |
| Current Transformer Test Date | CurrentTransformerTestDate | ElectricityMeter/CurrentTransformerTestDate | dd-mm-yyyy | xsd:date |

| | | | | |
|------------------------------|------------------------|---|---|--|
| Data Conversion | DataConversion | ElectricityMeter/DataConversion | VARCHAR2(50) | xsd:string maxLen = 50 |
| Data Validations | DataValidations | ElectricityMeter/DataValidations | VARCHAR2(50) | xsd:string maxLen = 50 |
| Estimation Instruction | EstimationInstructions | ElectricityMeter/EstimationInstructions | VARCHAR2(50) | xsd:string maxLen = 50 |
| GPS Coordinates - Latitude | GPSCoordinatesLat | ElectricityMeter/GPSCoordinatesLat | NUMERIC (s2.7) | xsd:decimal minIncl = 0 maxIncl = 99.9999999 totdig = 2 fracdig = 7 |
| GPS Coordinates - Longitude | GPSCoordinatesLong | ElectricityMeter/GPSCoordinatesLong | NUMERIC (s3.7) | xsd:decimal minIncl = 0 maxIncl = 999.9999999 totdig = 3 fracdig = 7 |
| Last Test Date | LastTestDate | ElectricityMeter/LastTestDate | dd-mmm-yyyy | xsd:date |
| Measurement Type | MeasurementType | ElectricityMeter/MeasurementType | VARCHAR2(4) | xsd:string maxLen = 4 |
| Meter Constant | Constant | ElectricityMeter/Constant | VARCHAR2(12) | xsd:string maxLen = 12 |
| Meter Hazard | Hazard | ElectricityMeter/Hazard | VARCHAR2(100) | xsd:string maxLen = 100 |
| Meter Installation Type Code | InstallationTypeCode | ElectricityMeter/InstallationTypeCode | VARCHAR2(8) | xsd:string maxLen = 8 |
| Meter Location | Location | ElectricityMeter/Location | VARCHAR2(200) See AddlSiteInfo (above) | xsd:string maxLen = 200 |
| Meter Manufacturer | Manufacturer | ElectricityMeter/Manufacturer | VARCHAR2(15) | xsd:string maxLen = 15 |
| Meter Model | Model | ElectricityMeter/Model | VARCHAR2(12) | xsd:string maxLen = 12 |
| Meter Point | Point | ElectricityMeter/Point | VARCHAR(2) | xsd:string maxLen = 2 |
| Meter Program | Program | ElectricityMeter/Program | VARCHAR2(30) | xsd:string maxLen = 30 |
| Meter Read Type | ReadTypeCode | ElectricityMeter/ReadTypeCode | VARCHAR(4) | xsd:string maxLen = 4 |
| Meter Route | Route | ElectricityMeter/Route | VARCHAR2(12) | xsd:string maxLen = 12 |
| Meter Serial ID Meter ID | SerialNumber | ElectricityMeter/SerialNumber | VARCHAR2(12) | xsd:string maxLen = 12 |

| | | | | |
|------------------------------|----------------------------|---|--------------|-----------------------------|
| (Different on two screens) | | | | |
| Status Code | Status | ElectricityMeter/Status | CHAR(1) | xsd:string with enumeration |
| Meter Use | Use | ElectricityMeter/Use | VARCHAR2(10) | xsd:string maxLen = 10 |
| Next Scheduled Read Date | NextScheduledReadDate | ElectricityMeter/NextScheduledReadDate | dd-mmm-yyyy | xsd:date |
| Next Test Date | NextTestDate | ElectricityMeter/NextTestDate | dd-mmm-yyyy | xsd:date |
| NMI | NMI | NMI | CHAR(10) | xsd:string maxLen = 10 |
| Passwords | Password | ElectricityMeter/Password | VARCHAR2(20) | xsd:string maxLen = 20 |
| Remote Phone Number | RemotePhoneNumber | ElectricityMeter/RemotePhoneNumber | VARCHAR2(12) | xsd:string maxLen = 12 |
| Test & Calibration Program | TestCalibrationProgram | ElectricityMeter/TestCalibrationProgram | VARCHAR2(50) | xsd:string maxLen = 50 |
| Test Performed By | TestPerformedBy | ElectricityMeter/TestPerformedBy | VARCHAR2(20) | xsd:string maxLen = 20 |
| Test Result | TestResult | ElectricityMeter/TestResult | VARCHAR2(4) | xsd:string maxLen = 4 |
| Test Result Notes | TestResultNotes | ElectricityMeter/TestResultNotes | VARCHAR2(50) | xsd:string maxLen = 50 |
| Transformer Location | TransformerLocation | ElectricityMeter/TransformerLocation | VARCHAR2(30) | xsd:string maxLen = 30 |
| Transformer Ratio | TransformerRatio | ElectricityMeter/TransformerRatio | VARCHAR2(20) | xsd:string maxLen = 20 |
| Transformer Type | TransformerType | ElectricityMeter/TransformerType | VARCHAR2(20) | xsd:string maxLen = 20 |
| User Access Rights | UserAccessRights | ElectricityMeter/UserAccessRights | VARCHAR2(50) | xsd:string maxLen = 50 |
| Voltage Transformer Location | VoltageTransformerLocation | ElectricityMeter/VoltageTransformerLocation | VARCHAR(50) | xsd:string maxLen = 50 |
| Voltage Transformer Type | VoltageTransformerType | ElectricityMeter/VoltageTransformerType | VARCHAR(50) | xsd:string maxLen = 50 |
| Voltage Transformer Ratio | VoltageTransformerRatio | ElectricityMeter/VoltageTransformerRatio | VARCHAR(50) | xsd:string maxLen = 50 |

| | | | | |
|------------------------------------|---------------------------------|--|---|--------------------------------|
| Voltage Transformer Accuracy Class | VoltageTransformerAccuracyClass | ElectricityMeter/VoltageTransformerAccuracyClass | VARCHAR(20) | xsd:string maxLen = 20 |
| Voltage Transformer Test | VoltageTransformerTest | ElectricityMeter/CurrentTransformerTest | VARCHAR2(20) | xsd:string maxLen = 20 |
| Voltage Transformer Test Date | VoltageTransformerTestDate | ElectricityMeter/VoltageTransformerTestDate | dd-mmm-yyyy | xsd:date |
| Start Date | FromDate | FromDate | dd-mmm-yyyy | xsd:dateTime |
| End Date | ToDate | ToDate | dd-mmm-yyyy | xsd:dateTime |
| Updated On | MaintenanceDate | MaintenanceDate | dd-mmm-yyyy (summary screen) dd-mmm-yyyy hh:mm:ss (detail screen) | xsd:dateTime |
| Created On | CreationDate | CreationDate | dd-mmm-yyyy (summary screen) dd-mmm-yyyy hh:mm:ss (detail screen) | xsd:dateTime |
| Activity Status | RowStatus | RowStatus | CHAR(1) | xsd:string with enumeration |

Table 46 CATS_DLF_Codes

| Browser Field Name | aseXML Data Element Name | aseXML Path | Browser Format | aseXML Data Type |
|--------------------|-----------------------------------|---|---------------------------------|--|
| DLF Code | DistributionLossFactorCode | DistributionLossFactorCode | VARCHAR2(4) | xsd:string maxLen = 4 |
| Description | DistributionLossFactorDescription | DistributionLossFactorDescription | VARCHAR2(50) | xsd:string maxLen = 50 |
| DLF Value | DistributionLossFactorValue | DistributionLossFactorValue | NUMBER(6,5) | xsd:decimal minIncl = 0 maxIncl = 2 totdig = 6 fracdig = 5 |
| Jurisdiction | JurisdictionCode | ElectricityStandingData/MasterData/JurisdictionCode | VARCHAR2(3) | xsd:string maxLen = 3 |
| Activity Status | RowStatus | RowStatus | CHAR(1) | xsd:string with enumeration |
| Start Date | FromDate | FromDate | dd-mmm-yyyy | xsd:dateTime |
| End Date | ToDate | ToDate | dd-mmm-yyyy | xsd:dateTime |
| Updated On | MaintenanceDate | MaintenanceDate | dd-mmm-yyyy (summary screen) | xsd:dateTime |

| | | | | |
|--|--------------|--------------|---|--------------|
| | | | dd-mmm-yyyy hh:mm:ss (detail screen) | |
| | CreationDate | CreationDate | dd-mmm-yyyy (summary screen) dd-mmm-yyyy hh:mm:ss (detail screen) | xsd:dateTime |

Table 47 CATS_Emb_Net_ID_Codes

| Browser Field Name | aseXML Data Element Name | aseXML Path | Browser Format | aseXML Data Type |
|--------------------|----------------------------|--|---|-----------------------------------|
| Code | EmbeddedNetworkIdentifier | EmbeddedNetworkIdentifier | VARCHAR2(10) | xsd:string maxLen = 10 |
| Description | EmbeddedNetworkDescription | EmbeddedNetworkDescription | VARCHAR2(50) | xsd:string maxLen = 50 |
| Locality/Suburb | SuburbOrPlaceOrLocality | ElectricityStandingData/MasterData/Address/AustralianAddress/SuburbOrPlaceOrLocality | VARCHAR2(46) | xsd:string maxLen = 46 |
| Postcode | PostCode | ElectricityStandingData/MasterData/Address/AustralianAddress/PostCode | VARCHAR2(4) | xsd:string pattern: [\p{N}]{4} |
| State | StateOrTerritory | ElectricityStandingData/MasterData/Address/AustralianAddress/StateOrTerritory | VARCHAR2(3) | xsd:string with enumerations |
| Activity Status | RowStatus | RowStatus | CHAR(1) | xsd:string with enumeration |
| Start Date | FromDate | FromDate | dd-mmm-yyyy | xsd:dateTime |
| End Date | ToDate | ToDate | dd-mmm-yyyy | xsd:dateTime |
| Updated On | MaintenanceDate | MaintenanceDate | dd-mmm-yyyy (summary screen) dd-mmm-yyyy hh:mm:ss (detail screen) | xsd:dateTime |
| | CreationDate | CreationDate | dd-mmm-yyyy (summary screen) dd-mmm-yyyy hh:mm:ss (detail screen) | xsd:dateTime |

Table 48 CATS_NMI_Data

| Browser Field Name | aseXML Data Element Name | aseXML Path | Browser Format | aseXML Data Type |
|---|-------------------------------------|--|----------------|----------------------------------|
| NMI | NMI | NMI | CHAR(10) | xsd:string maxLen = 10 |
| NMI Classification Code | NMIClassificationCode | ElectricityStandingData /MasterData/ NMIClassificationCode | VARCHAR2(8) | xsd:string maxLen = 8 |
| Status Code | Status | ElectricityStandingData /MasterData/Status | CHAR(1) | xsd:string maxLen = 1 |
| TNI Code | TransmissionNodeIdentifier | ElectricityStandingData /MasterData/TransmissionNodeIdentifier | VARCHAR2(4) | xsd:string maxLen = 4 |
| TNI Code 2 | TransmissionNodeIdentifier2 | ElectricityStandingData /MasterData/TransmissionNodeIdentifier2 | VARCHAR2(4) | xsd:string maxLen = 4 |
| Shared Isolation Point Flag | SharedIsolationPointFlag | ElectricityMeter/SharedIsolationPointFlag | CHAR(1) | xsd:string maxLen = 1 |
| Meter Malfunction Exemption Number | MeterMalfunctionExemptionNumber | ElectricityMeter/MeterMalfunctionExemptionNumber | VARCHAR2(8) | xsd:string maxLen = 8 |
| Meter Malfunction Exemption Expiry Date | MeterMalfunctionExemptionExpiryDate | ElectricityMeter/MeterMalfunctionExemptionExpiryDate | dd-mmm-yyyy | xsd:date |
| Jurisdiction Code | JurisdictionCode | JurisdictionCode | VARCHAR2(3) | xsd:string maxLen = 3 |
| DLF Code | DistributionLossFactorCode | ElectricityStandingData /MasterData/DistributionLossFactorCode | VARCHAR2(4) | xsd:string maxLen = 4 |
| Connection Configuration | ConnectionConfiguration | ElectricityMeter/ConnectionConfiguration | VARCHAR2(2) | xsd:string maxLen = 2 |
| Embedded Network ID (Child) | ChildEmbeddedNetworkIdentifier | ElectricityStandingData /MasterData/ChildEmbeddedNetworkIdentifier | VARCHAR2(10) | xsd:string maxLen = 10 |
| Embedded Network (Parent) | ParentEmbeddedNetworkIdentifier | ElectricityStandingData /MasterData/ParentEmbeddedNetworkIdentifier | VARCHAR2(10) | xsd:string maxLen = 10 |
| Building / Property Name | BuildingOrPropertyName | ElectricityStandingData /MasterData/Address/AustralianAddress/StructuredAddress/BuildingOrPropertyName | VARCHAR2(30) | xsd:string maxLen = 30 x 2 |

| | | | | |
|---------------------|--------------------|--|--------------|--|
| Lot Number | LotNumber | ElectricityStandingData /MasterData/ Address/AustralianAddress/StructuredAddress/Lot/LotNumber | VARCHAR2(6) | xsd:string pattern: [\p{L}\p{N}\p{P}\s]{1,6} |
| Flat/Unit Number | FlatOrUnitNumber | ElectricityStandingData /MasterData/Address/ AustralianAddress/StructuredAddress/FlatOrUnit/FlatOrUnitNumber | VARCHAR2(7) | xsd:string pattern: [\p{L}\p{N}\p{P}\s]{1,7} |
| Flat/Unit Type | FlatOrUnitType | ElectricityStandingData /MasterData/Address/ AustralianAddress/StructuredAddress/FlatOrUnit/FlatOrUnitType | VARCHAR2(4) | xsd:string with enumerations |
| Floor/Level Number | FloorOrLevelNumber | ElectricityStandingData /MasterData/Address/ AustralianAddress/StructuredAddress/FloorOrLevel/FloorOrLevelNumber | VARCHAR2(5) | xsd:string [\p{L}\p{N}\p{P}\s]{1,5} |
| Floor/Level Type | FloorOrLevelType | ElectricityStandingData /MasterData/Address/ AustralianAddress/StructuredAddress/FloorOrLevel/FloorOrLevelType | VARCHAR2(2) | xsd:string with enumerations |
| House Number | HouseNumber | ElectricityStandingData /MasterData/Address/ AustralianAddress/StructuredAddress/House/HouseNumber | NUMBER(5) | xsd:nonNegativeInteger maxIncl = 99999 |
| House Number Suffix | HouseNumberSuffix | ElectricityStandingData /MasterData/Address/ AustralianAddress/StructuredAddress/House/HouseNumberSuffix | VARCHAR2(1) | xsd:string pattern: [\p{L}\p{N}]{1} |
| House Number To | HouseNumberTo | ElectricityStandingData /MasterData/Address/ AustralianAddress/StructuredAddress/House/HouseNumberTo | NUMBER(5) | xsd:nonNegativeInteger maxIncl = 99999 |
| Street Name | StreetName | ElectricityStandingData /MasterData/Address/ AustralianAddress/StructuredAddress/Street/StreetName | VARCHAR2(30) | xsd:string pattern: [\p{L}\p{N}\s\-']{1,30} |
| Street Name Suffix | StreetSuffix | ElectricityStandingData /MasterData/Address/ AustralianAddress/ | VARCHAR2(2) | xsd:string with enumerations |

| | | | | |
|----------------------|-------------------------|--|---------------|--|
| | | StructuredAddress/Street/StreetSuffix | | |
| Street Type | StreetType | ElectricityStandingData/MasterData/Address/AustralianAddress/StructuredAddress/Street/StreetType | VARCHAR2(4) | xsd:string with enumerations |
| Suburb/Locality | SuburbOrPlaceOrLocality | ElectricityStandingData/MasterData/Address/AustralianAddress/SuburbOrPlaceOrLocality | VARCHAR2(46) | xsd:string maxLength = 46 |
| Location Descriptor | LocationDescriptor | ElectricityStandingData/MasterData/Address/AustralianAddress/StructuredAddress/LocationDescriptor | VARCHAR2(200) | xsd:string pattern: [\p{L}\p{N}\p{P}\s]{1,200} |
| Postcode | PostCode | ElectricityStandingData/MasterData/Address/AustralianAddress/PostCode | VARCHAR2(4) | xsd:string pattern: [\p{N}]{4} |
| State | StateOrTerritory | ElectricityStandingData/MasterData/Address/AustralianAddress/StateOrTerritory | VARCHAR2(3) | xsd:string with enumerations |
| DPID | DeliveryPointIdentifier | ElectricityStandingData/MasterData/Address/AustralianAddress/StructuredAddress/DeliveryPointIdentifier | NUMBER(8) | xsd:nonNegativeInteger minIncl = 10000000 maxIncl = 99999999 |
| GNAF PID | GNAFPID | ElectricityStandingData/MasterData/Address/AustralianAddress/StructuredAddress/GNAFPID | VARCHAR2(20) | xsd:string maxLength = 20 |
| Section Number | SectionNumber | ElectricityStandingData/MasterData/Address/AustralianAddress/StructuredAddress/SectionNumber | VARCHAR2(20) | xsd:string maxLength = 20 |
| DP Number | DPNumber | ElectricityStandingData/MasterData/Address/AustralianAddress/StructuredAddress/DPNumber | VARCHAR2(20) | xsd:string maxLength = 20 |
| Unstructured Address | AddressLine | ElectricityStandingData/MasterData/Address/AustralianAddress/UnstructuredAddress/Address/AddressLine | VARCHAR2(80) | xsd:string maxLength = 80 x 3 |

| | | | | |
|--|-----------------------------|--|--|-----------------------------|
| Aggregate Flag | Aggregate | ElectricityStandingData /MasterData/Aggregate | CHAR(1) | xsd:string with enumeration |
| Start Date | FromDate | FromDate | dd-mmm-yyyy | xsd:dateTime |
| End Date | ToDate | ToDate | dd-mmm-yyyy | xsd:dateTime |
| Updated On | MaintenanceDate | MaintenanceDate | dd-mmm-yyyy (summary screen) dd-mmm-yyyy hh:mm:ss (detail screen) | xsd:dateTime |
| Created On | CreationDate | CreationDate | dd-mmm-yyyy (summary screen) dd-mmm-yyyy hh:mm:ss (detail screen) | xsd:dateTime |
| Activity Status | RowStatus | RowStatus | CHAR(1) | xsd:string with enumeration |
| Feeder Class | Feeder Class | ElectricityStandingData /MasterData/FeederClass | VARCHAR2(15) | xsd:string maxLen = 15 |
| Customer Classification Code | CustomerClassification Code | ElectricityStandingData /MasterData/CustomerClassificationCode | VARCHAR2(20) | xsd:string maxLen = 20 |
| Customer Classification Threshold Code | CustomerThresholdCode | ElectricityStandingData /MasterData/CustomerThresholdCode | VARCHAR2(20) | xsd:string maxLen = 20 |
| NMI | NMI | NMI | CHAR(10) | xsd:string maxLen = 10 |
| Suffix | Suffix | ElectricityDataStream/ Suffix | VARCHAR2(2) | xsd:string maxLen = 2 |
| Status Code | Status | ElectricityDataStream/ Status | CHAR(1) | xsd:string maxLen = 1 |
| Average Daily Load | AveragedDailyLoad | ElectricityDataStream/ AveragedDailyLoad | NUMBER(10) | xsd:integer |
| Type | DataStreamType | ElectricityDataStream/ DataStreamType | CHAR(1) | xsd:string with enumeration |
| Profile Name | ProfileName | ElectricityDataStream/ ProfileName | VARCHAR2(10) | xsd:string maxLen = 10 |
| Start Date | FromDate | FromDate | dd-mmm-yyyy | xsd:dateTime |
| End Date | ToDate | ToDate | dd-mmm-yyyy | xsd:dateTime |
| Updated On | MaintenanceDate | MaintenanceDate | dd-mmm-yyyy (summary screen) dd-mmm-yyyy hh:mm:ss (detail screen) | xsd:dateTime |

| | | | | |
|-----------------|--------------|--------------|---|--------------------------------|
| Created On | CreationDate | CreationDate | dd-mmm-yyyy (summary screen) dd-mmm-yyyy hh:mm:ss (detail screen) | xsd:dateTime |
| Activity Status | RowStatus | RowStatus | CHAR(1) | xsd:string with enumeration |

Table 49 CATS_Register_Identifier

| Browser Field Name | aseXML Data Element Name | aseXML Path | Browser Format | aseXML Data Type |
|---|------------------------------|---|----------------|--|
| NMI | NMI | NMI | CHAR(10) | xsd:string maxLen = 10 |
| Meter Serial ID Meter ID (Different on two screens) | SerialNumber | SerialNumber | VARCHAR2(12) | xsd:string maxLen = 12 |
| Register ID | RegisterID | ElectricityMeterRegisterDetail/RegisterID | VARCHAR2(10) | xsd:string maxLen = 10 |
| Network Tariff Code | NetworkTariffCode | ElectricityMeterRegisterDetail/NetworkTariffCode | VARCHAR2(10) | xsd:string maxLen = 10 |
| Network Tariff Additional Information | NetworkAdditionalInformation | ElectricityMeterRegisterDetail/NetworkAdditionalInformation | VARCHAR2(4000) | xsd:string |
| Unit of Measure | UnitOfMeasure | ElectricityMeterRegisterDetail/UnitOfMeasure | VARCHAR2(5) | xsd:string maxLen = 5 |
| Time of Day | TimeOfDay | ElectricityMeterRegisterDetail/TimeOfDay | VARCHAR2(10) | xsd:string maxLen = 10 |
| Multiplier | Multiplier | ElectricityMeterRegisterDetail/Multiplier | Number(13,5) | xsd:decimal |
| Dial Format | DialFormat | ElectricityMeterRegisterDetail/DialFormat | Number(4,2) | xsd:decimal minIncl = 0 maxIncl = 99.99 totdig = 4 fracdig = 2 |
| Suffix | Suffix | ElectricityMeterRegisterDetail/Suffix | VARCHAR2(2) | xsd:string maxLen = 2 |
| Controlled Load | ControlledLoad | ElectricityMeterRegisterDetail/ControlledLoad | VARCHAR2(100) | xsd:string maxLen = 100 |
| Status Code | Status | ElectricityMeterRegisterDetail/Status | CHAR(1) | xsd:string with enumeration |

| | | | | |
|-----------------------------|-----------------|--|--|-----------------------------|
| Actual/Cumulative Indicator | ConsumptionType | ElectricityMeterRegisterDetail/ConsumptionType | CHAR(1) | xsd:string with enumeration |
| Demand 1 | Demand1 | ElectricityMeterRegisterDetail/Demand1 | Number(8) | xsd:integer totdig = 8 |
| Demand 2 | Demand2 | ElectricityMeterRegisterDetail/Demand2 | Number(8) | xsd:integer totdig = 8 |
| Start Date | FromDate | FromDate | dd-mmm-yyyy | xsd:dateTime |
| End Date | ToDate | ToDate | dd-mmm-yyyy | xsd:dateTime |
| Updated On | MaintenanceDate | MaintenanceDate | dd-mmm-yyyy (summary screen) dd-mmm-yyyy hh:mm:ss (detail screen) | xsd:dateTime |
| Created On | CreationDate | CreationDate | dd-mmm-yyyy (summary screen) dd-mmm-yyyy hh:mm:ss (detail screen) | xsd:dateTime |
| Activity Status | RowStatus | RowStatus | CHAR(1) | xsd:string with enumeration |

Table 50 CATS_NMI_Participant_Relations

| Browser Field Name | aseXML Data Element Name | aseXML Path | Browser Format | aseXML Data Type |
|--------------------|--------------------------|-----------------|--|-----------------------------|
| Participant ID | Party | Party | VARCHAR2(10) | xsd:string |
| NMI | NMI | NMI | CHAR(10) | xsd:string maxLen = 10 |
| Role | Role | Role | VARCHAR2(4) | xsd:string maxLen = 4 |
| Start Date | FromDate | FromDate | dd-mmm-yyyy | xsd:dateTime |
| End Date | ToDate | ToDate | dd-mmm-yyyy | xsd:dateTime |
| Updated On | MaintenanceDate | MaintenanceDate | dd-mmm-yyyy (summary screen) dd-mmm-yyyy hh:mm:ss (detail screen) | xsd:dateTime |
| Created On | CreationDate | CreationDate | dd-mmm-yyyy (summary screen) dd-mmm-yyyy hh:mm:ss (detail screen) | xsd:dateTime |
| Activity Status | RowStatus | RowStatus | CHAR(1) | xsd:string with enumeration |

17. EXAMPLES OF TYPICAL FIELD VALUES

This section provides examples of typical sets of data element values associated with different types of *connection points*.

The data shown in each example is as shown in the Browser. This reverses the sequence of the day-month-year communicated via aseXML transactions.

Table 51 CATS_Meter_Register

| Data Element Name (as it appears in XML documents) | Browser Field Name(as it appears in MSATS Browser) | Basic Example | Interval Example | Data Element Name |
|---|---|--|---|---------------------------------|
| AdditionalSiteInformation | Additional Site Information | MTR ON SITE AT 17B | Red Rooster | AdditionalSiteInformation |
| AssetManagementPlan | Asset Management Plan | CITIPower METER MANAGEMENT PLAN | PER CE DOC: TYPES 1-4 ASSET MANAGEMENT & TEST PLAN | AssetManagementPlan |
| CalibrationTables | Calibration Tables | Q | | CalibrationTables |
| CommunicationsEquipment Type | Communication Equipment Type | FACE | 96 | CommunicationsEquipmentType |
| CommunicationsProtocol | Communication Protocol | NA | EMAIL MINI GATEWAY S/N SU121 MV90 2 TBD TBD | CommunicationsProtocol |
| CurrentTransformerLocation | Current Transformer Location | | BEHIND DOOR | CurrentTransformerLocation |
| CurrentTransformerType | Current Transformer Type | | A | CurrentTransformerType |
| CurrentTransformerRatioAvailable | Current Transformer Ratio Available | | 20 / 50 / 100 : 5 | CurrentTransformerRatio |
| CurrentTransformerRatioConnecte d | Current Transformer Ratio Connected | | 400 : 5 | CurrentTransformerRatio |
| CurrentTransformerAccuracyClass | Current Transformer Accuracy Class | | 0.2M | CurrentTransformerAccuracyClass |
| CurrentTransformerTest | Current Transformer Test | | Tested | CurrentTransformerTest |
| CurrentTransformerTestDate | Current Transformer Test Date | | 01-01-2020 | CurrentTransformerTestDate |
| DataConversion | Data Conversion | .0005 | .0005 | DataConversion |
| DataValidations | Data Validations | As per Metrology Procedure Part B | As per Metrology Procedure Part B | DataValidations |
| EstimationInstructions | Estimation Instruction | As per Metrology Procedure Part B (TYPES -61, 62, 65) | As per Metrology Procedure Part B (TYPES -14) | EstimationInstructions |
| GPSCoordinates - Latitude | GPSCoordinatesLat | -37.8886755 | -37.8886755 | GPSCoordinatesLat |
| GPSCoordinates - Longitude | GPSCoordinatesLong | +145.1410361 | +145.1410361 | GPSCoordinatesLong |

STANDING DATA FOR MSATS



| Data Element Name (as it appears in XML documents) | Browser Field Name(as it appears in MSATS Browser) | Basic Example | Interval Example | Data Element Name |
|---|---|--------------------------------|---------------------|-----------------------|
| LastTestDate | Last Test Date | 07-05-2004 | 07-03-2004 | LastTestDate |
| MeasurementType | Measurement Type | EQ | EQ | MeasurementType |
| Constant | Meter Constant | 40 | .5 | Constant |
| Hazard | Meter Hazard | | Asbestos | Hazard |
| InstallationTypeCode | Meter Installation Type Code | BASIC | COMMS4 | InstallationTypeCode |
| Location | Meter Location | ON SUB POLE | BEHIND DOOR | Location |
| Manufacturer | Meter Manufacturer | EMAIL | EDMI | Manufacturer |
| Model | Meter Model | Q3 | Q4 | Model |
| Point | Meter Point | 01 | 01 | Point |
| Program | Meter Program | 30 - NP 3.2 CT FACE PLATE READ | 10- AE CT kVAR 9600 | Program |
| ReadTypeCode | Meter Read Type | MV3M | RTDA | ReadTypeCode |
| Route | Meter Route | 11618 | 1305 | Route |
| SerialNumber | Meter Serial ID, Meter ID (Different on two screens) | 525811 | 201000299 | SerialNumber |
| Status | Status Code | C | C | Status |
| Use | Meter Use | REVENUE | REVENUE | Use |
| NextScheduledReadDate | Next Scheduled Read Date | 04-10-2006 | | NextScheduledReadDate |
| NextTestDate | Next Test Date | 17-05-2004 | 10-05-2004 | NextTestDate |
| NMI | NMI | 1122334455 | 1122334455 | NMI |

STANDING DATA FOR MSATS



| Data Element Name (as it appears in XML documents) | Browser Field Name(as it appears in MSATS Browser) | Basic Example | Interval Example | Data Element Name |
|---|---|------------------------|-------------------------------------|---------------------------------|
| Password | Passwords | 12345 | 12345 | Password |
| RemotePhoneNumber | Remote Phone Number | FACE READ | 0555 825 987 | RemotePhoneNumber |
| TestCalibrationProgram | Test & Calibration Program | AS PER AS/NZ 1284 | AS PER AS/NZ 1284 | TestCalibrationProgram |
| TestPerformedBy | Test Performed By | Ron Sargeant | SMU | TestPerformedBy |
| TestResult | Test Result | Pass | Pass | TestResult |
| TestResultNotes | Test Result Notes | CHECK AND RESEAL METER | METER TEST CORRECT | TestResultNotes |
| TransformerLocation | Transformer Location | | REAR OFBUILDING | TransformerLocation |
| TransformerRatio | Transformer Ratio | | 1500/5 | TransformerRatio |
| TransformerType | Transformer Type | | 24 WIRE WOUND | TransformerType |
| UserAccessRights | User Access Rights | AS PER AS/NZ 1284 | MDP ONLY ACCESS | UserAccessRights |
| VoltageTransformerLocation | Voltage Transformer Location | | BEHIND DOOR | VoltageTransformerLocation |
| VoltageTransformerType | Voltage Transformer Type | | IVT (Inductive Voltage Transformer) | VoltageTransformerType |
| VoltageTransformerRatio | Voltage Transformer Ratio | | 3300 : 110 | VoltageTransformerRatio |
| VoltageTransformerAccuracyClass | Voltage Transformer Accuracy Class | | 0.01M | VoltageTransformerAccuracyClass |
| VoltageTransformerTest | Voltage Transformer Test | | Tested | VoltageTransformerTest |
| VoltageTransformerTestDate | Voltage Transformer Test Date | | 01-01-2020 | VoltageTransformerTestDate |
| FromDate | Start Date | 14-03-1990 | 16-03-2002 | FromDate |
| ToDate | End Date | 31-12-9999 | 18-07-2006 | ToDate |
| MaintenanceDate | Updated On | 31-12-999 00:00:00 | 31-12-999 00:00:00 | MaintenanceDate |
| CreationDate | Created On | 19-03-1990 00:01:00 | 18-03-2002 00:01:00 | CreationDate |

Table 52 CATS_DLF_Codes

| Data Element Name | Browser Field Name | Basic & Interval Example |
|-----------------------------------|------------------------|--------------------------|
| DistributionLossFactorCode | DLF Code | NHV1 |
| DistributionLossFactorDescription | Description | UMPLP - High Voltage |
| DistributionLossFactorValue | [The actual DLF value] | 1.11111 |
| JurisdictionCode | Jurisdiction Code | SA |
| RowStatus | Activity Status | A |
| FromDate | Start Date | 01-07-1999 |
| ToDate | End Date | 30-06-2000 |
| MaintenanceDate | Updated On | 31-05-2000 00:30:27 |
| CreationDate | | 01-06-1999 00:23:32 |

Table 53 CATS_Emb_Net_ID_Codes

| Data Element Name | Browser Field Name | Basic & Basic Example |
|----------------------------|--------------------|---------------------------------|
| EmbeddedNetworkIdentifier | Code | SE01008111 |
| EmbeddedNetworkDescription | Description | Kingston-On-Murray Caravan Park |
| SuburbOrPlaceOrLocality | Suburb / Locality | Kingston-On-Murray |
| PostCode | Postcode | 5331 |
| StateOrTerritory | State | SA |
| RowStatus | Activity Status | A |
| FromDate | Start Date | 5/04/2003 |
| ToDate | End Date | 31/12/9999 |
| MaintenanceDate | Updated On | 31/12/9999 |
| | CreationDate | 1/04/2003 13:23 |

Table 54 CATS_NMI_Data

| Data Element Name | Browser Field Name | Basic Example | Interval Example |
|---|---|---------------|------------------|
| NMI | NMI | 122334451 | 1122334455 |
| NMIClassificationCode | NMI Classification Code | SMALL | LARGE |
| MasterData/Status | Status Code | A | G |
| TransmissionNodeIdentifier | TNI Code | NRGE | SBER |
| TransmissionNodeIdentifier 2 | TNI Code 2 | | SORA |
| Shared Isolation Point Flag | Shared Isolation Point Flag | N | Y |
| Meter Malfunction Exemption Number | Meter Malfunction Exemption Number | ERF 0001 | ERF 0001 |
| Meter Malfunction Exemption Expiry Date | Meter Malfunction Exemption Expiry Date | 07-05-2020 | 07-05-2020 |
| JurisdictionCode | Jurisdiction Code | NSW | SA |

| | | | |
|---------------------------------|-----------------------------|---------------------|-----------------------|
| ConnectionConfiguration | Connection Configuration | L1 | H3 |
| DistributionLossFactorCode | DLF Code | NRGE | NLV2 |
| ChildEmbeddedNetworkIdentifier | Embedded Network ID (Child) | NS01008111 | SE01008111 |
| ParentEmbeddedNetworkIdentifier | Embedded Network (Parent) | NS01008111 | SE01008111 |
| BuildingOrPropertyName | Building / Property Name | BP | SHELL |
| LotNumber | Lot Number | 22 | 23 |
| FlatOrUnitNumber | Flat/Unit Number | 1 | 2 |
| FlatOrUnitType | Flat/Unit Type | U | U |
| FloorOrLevelNumber | Flat/Unit Number | 1 | 1 |
| FloorOrLevelType | Floor/Level Type | FL | FL |
| HouseNumber | House Number | 6 | 10 |
| HouseNumberSuffix | House Number Suffix | A | B |
| HouseNumberTo | House Number To | 10 | 17 |
| StreetName | Street Name | BORIS | DORIS |
| StreetSuffix | Street Name Suffix | N | W |
| StreetType | Street Type | DR | ST |
| SuburbOrPlaceOrLocality | Suburb/Locality | ORANGE | LOXTON |
| LocationDescriptor | Location Descriptor | CNR FRED ST | SHELL SERVICE STATION |
| PostCode | Postcode | 2211 | 5333 |
| StateOrTerritory | State | NSW | SA |
| DeliveryPointIdentifier | DPID | 01234567 | 12345678 |
| GNAFPID | GNAF PID | GDA2020 | GDA2020 |
| SectionNumber | Section Number | Section 23K | Section 23K |
| DPNumber | DP Number | DP 825310 | DP 825310 |
| AddressLine | Unstructured Address 1 | Text | Text |
| AddressLine | Unstructured Address 2 | Text | Text |
| AddressLine | Unstructured Address 3 | Text | Text |
| Aggregate | Aggregate Flag | Y | Y |
| FromDate | Start Date | 01-06-2004 | 01-06-2001 |
| ToDate | End Date | 31-12-9999 | 01-01-2003 |
| MaintenanceDate | Updated On | 31-12-9999 00:00:00 | 05-01-2003 00:01:00 |
| CreationDate | Created On | 04-01-2004 09:31:00 | 01-06-2001 00:01:00 |
| RowStatus | Activity Status | A | A |
| FeederClass | Feeder Class | ERGUD | ERGUD |

| | | | |
|-----------------------------|-------------------------|-------------|----------|
| Customer ClassificationCode | Customer Classification | RESIDENTIAL | BUSINESS |
| CustomerThresholdCode | Customer Threshold | LOW | HIGH |

Table 55 CATS_NMI_Data_Stream

| Data Element Name | Browser Field Name | Basic Example | Interval Example |
|---|--------------------|---------------------|---------------------|
| NMI | NMI | 1100445566 | 2211335544 |
| ElectricityDataStream/Suffix | Suffix | 31 | N1 |
| ElectricityDataStream/Status | Status Code | A | A |
| ElectricityDataStream/AveragedDailyLoad | Average Daily Load | 5 | 800 |
| ElectricityDataStream/DataStreamType | Type | C | I |
| ElectricityDataStream/ProfileName | Profile Name | NSLP | NOPROF |
| FromDate | Start Date | 31-12-2001 | 01-06-2005 |
| ToDate | End Date | 31-12-9999 | 31-12-9999 |
| MaintenanceDate | Updated On | 02-01-2004 13:27:58 | 31-12-9999 |
| CreationDate | Created On | 19-01-2002 17:15:23 | 05-06-2005 15:12:20 |
| RowStatus | Activity Status | I | A |

Table 56 CATS_Register_Identifier

| Data Element Name | Browser Field Name | Basic Example | Interval Example |
|------------------------------|---|---------------------------------|------------------------|
| NMI | NMI | 1100445566 | 2211335544 |
| SerialNumber | Meter Serial ID Meter ID (Different on two screens) | 000012345 | 112258 |
| RegisterID | Register ID | 1 | E1 |
| NetworkTariffCode | Network Tariff Code | BLNB2CO | MB2RI |
| NetworkAdditionalInformation | Network Tariff Additional Information | General Supply Non TOU Eligible | LV TOU Demand Eligible |
| UnitOfMeasure | Unit of Measure | KWH | KWH |
| TimeOfDay | Time of Day | ALLDAY | ALLDAY |
| Multiplier | Multiplier | 1.00000 | 120.00000 |
| DialFormat | Dial Format | 5.00 | 5.10 |
| Suffix | Suffix | 11 | E1 |
| ControlledLoad | Controlled Load | HWLoad | No |
| Status | Status Code | C | C |

| | | | |
|-----------------|-----------------------------|---------------------|---------------------|
| ConsumptionType | Actual/Cumulative Indicator | C | A |
| Demand1 | Demand 1 | 0 | 0 |
| Demand2 | Demand 2 | 0 | 0 |
| FromDate | Start Date | 01-08-2004 | 01-06-2005 |
| ToDate | End Date | 31-12-9999 | 31-12-9999 |
| MaintenanceDate | Updated On | 31-12-9999 | 31-12-9999 |
| CreationDate | Created On | 01-11-2005 22:30:30 | 05-06-2005 09:09:09 |
| RowStatus | Activity Status | A | A |

18. DATA TYPE CONVENTIONS

The Browser formats used in section 16 are as defined in the following table.

The value of "x" must be positive and cannot be zero.

For explanation of the aseXML data types shown in section 16 refer

<http://www.w3.org/TR/xmlschema-0/#simpleTypesTable>

Table: Browser Formats

| | Format | Definition |
|---|-------------|---|
| 1 | CHAR(x) | Indicates a field that can only contain alphanumeric characters and must contain exactly "x" characters. Note that leading and trailing "spaces" are considered significant (i.e. form part of the "x" characters for the field). |
| 2 | VARCHAR2(x) | Indicates a character field containing up to "x" characters. |
| 3 | NUMBER(x) | Indicates a positive integer (zero or above) up to "x" significant digits long; any leading zeroes are not significant and hence "050" is equivalent to "50". |
| 4 | NUMBER(x.y) | Indicates a positive number with up to "x" significant characters to the left of the decimal point and "y" decimal places after the decimal point (trailing zeros are optional). In other words, the maximum length of the field as a whole is "x"+"y"+1 characters (the +1 reserving space for the decimal point). |