

MSATS PROCEDURES

NATIONAL METERING IDENTIFIER

PREPARED BY: AEMO Markets
VERSION: 6
EFFECTIVE DATE: 01 December 2017
STATUS: DRAFT

Approved for distribution and use by:

APPROVED BY: [NAME]
TITLE: [Title]

DATE: // 20

VERSION RELEASE HISTORY

Version	Effective Date	Summary of Changes
5	16/07/2006	<p>Added changes agreed as part of the CATS 2.4 MSATS Procedures: CATS Procedures Part 1 Principles and Obligations Version 2.4 that were missed from version 4. This includes the removal of the zero first character row from the consumption energy Data Suffix table.</p> <p>Added Amps to the Volts row of Table 1. Updated diagrams to a consistent format.</p> <p>Added diagrams of twin element interval meters at sections 12.4 and 12.5. Removed diagram of accumulation and interval metering at a site.</p> <p>Amendments to reflect changes developed as part of the Metrology Harmonisation project, including the development of the NEM Metrology Procedure.</p> <p>Relocated version history.</p> <p>Minor typographical amendments and corrections.</p>
5.1	August 2009	Update to AEMO format
6	01 Dec 2017	<p>Updated to incorporate changes resulting from:</p> <ul style="list-style-type: none"> • National Electricity Amendment (Expanding competition in metering and related services) Rule 2015. No.12; • National Electricity Amendment (Embedded Networks) Rule 2015 No. 15; and • National Electricity Amendment (Meter Replacement Processes) Rule 2016 No. 2.

CONTENTS

1. INTRODUCTION	5
1.1. Purpose and Scope	5
1.2. Definitions and Interpretation	5
1.3. Related AEMO Documents	5
2. ALLOCATION AND ISSUE OF NMIS	6
2.1. NMI Allocation by AEMO	6
2.2. Issue of NMIs by LNSPs and ENMs	6
3. NMI STRUCTURE	6
4. NMI REGISTERS	7
5. NMI CHECKSUM	7
6. DATASTREAM SUFFIX	7
7. DATASTREAM SUFFIX FOR INTERVAL METERING DATA	8
7.1. Datastream Suffix for Accumulated Metering Data	9
7.2. Wholesale Connection Points	9
8. CONNECTION POINTS WITH CHECK METERING	10
9. NMI RULES	10
9.1. NMI Allocation and Verification	10
9.2. NMI Decommissioning	10
10. UTILISATION OF NMI FOR AEMO DATA	12
10.1. Data Delivery to AEMO (MSATS System)	12
11. EXAMPLES OF NMI APPLICATION – INTERVAL METERING DATA	12
11.1. One End User metered on the secondary side of transformer	13
11.2. One End User, multiple metered on the secondary side of transformer	14
11.3. One End User, previously two tariff metering, e.g. general supply & off-peak on secondary side of transformer	14
11.4. One End User, two controlled loads, one twin element meter	15
11.5. One End User, two twin element meters	15
11.6. One End User, multiple meters on secondary side of multiple transformers in the same substation building an LV switchboard in common switchroom	16
11.7. Three End Users, metered on secondary side of multiple transformers in the same substation building	16
11.8. One End User, two separate HV supplies to two separate substations, both metered on secondary side of the transformers	17
11.9. One End User, two separate substations adjacent to each other or one single substation with two separate transformers in a single substation, with a “normally open” point separating the HV supplies into two sources	18
11.10. One End User, two separate substations adjacent to each other or one single substation with two separate transformers, with the HV supply originating from a single source	18
11.11. One End User, two separate substations not adjacent to each other but on same premises	19

11.12. Multiple End Users, High rise building	20
11.13. One End User with multiple supply points	21
11.14. One End User with Standby Supply	21
11.15. One End User or Participant, Wholesale Metering at Transmission Node	22
11.16. One End User or Participant, Wholesale Metering at Transmission Node	23
11.17. One End User, Wholesale Metering at Transmission Node	24
11.18. Street Lighting (Type 7 Metering Installation)	25
12. EXAMPLES OF NMI APPLICATION – ACCUMULATED ENERGY DATA	26
12.1. Single Meter with Single Datastream	26
12.2. Two Meters each with Single Datastream	26
12.3. Two Meter Installation, One Meter Recording Consumption for a Controlled Load	26
12.4. Three Datastream, One Meter with Single Measurement Element	27
12.5. Multi-function Meter	27
12.6. Two Multi-function Meters	27
13. ENERGY DIRECTION FLOWS	28
14. ALLOCATION OF NMIS FOR TYPE 7 METERING INSTALLATIONS	29
14.1. Common Requirements across the NEM	29
APPENDIX A. SAMPLE JAVA CODE FOR NMI CHECKSUM	30
APPENDIX B. EXAMPLES	32

TABLES

Table 1 Datastream Suffixes for Interval Metering Data	8
Table 2 Datastream Suffixes for Accumulated Metering Data	9
Table 3 Example NMI Results	33
Table 4 NMIs and NMI Checksums	33

1. INTRODUCTION

1.1. Purpose and Scope

This National Metering Identifier Procedure (**Procedure**) is an MSATS Procedure. It sets out the structure for *NMIs* to be used in the *NEM*, and details Datastreams for each category of *metering installation* and addresses the matters contemplated in clauses 7.8.2(d)(2), and 7.8.2(ea) (eb) & (ec) of the NER.

The successful operation of the *NEM* relies on:

- **p**Positive identification of *connection points*;
- **a**A verifiable linkage between *connection points*, [NMI Standing Data](#) and *metering data*; and
- **a**An audit trail for *metering data* collection and processing.

The *NMI* is a unique identifier for each *connection point*, an index against which other essential data can be managed, and it is crucial to the accurate management of End User registration and transfer, *connection point* change control and data aggregation and transfer.

1.2. Definitions and Interpretation

The Retail Electricity Market Procedures – Glossary and Framework:

- (a) is incorporated into and forms part of this document; and
- (b) should be read with this Procedure.

1.3. Related AEMO Documents

Title	Location
Retail Electricity Market Procedures – Glossary and Framework	http://aemo.com.au/Electricity/National-Electricity-Market-NEM/Retail-and-metering/Glossary-and-Framework
MSATS Procedures	http://aemo.com.au/Electricity/National-Electricity-Market-NEM/Retail-and-metering/Market-Settlement-and-Transfer-Solutions
Metrology Procedure Part A	http://aemo.com.au/Electricity/National-Electricity-Market-NEM/Retail-and-metering
NMI Allocation List	http://aemo.com.au/-/media/Files/PDF/NMI-Allocation-List-v8-December-2014.ashx

2. ALLOCATION AND ISSUE OF NMIS

2.1. NMI Allocation by AEMO

- (a) NMIs are allocated by AEMO for issue by LNSPs (for *connection points*) or ENMs (for *child connection points*) in accordance with this Procedure.
- ~~(b)~~ Blocks of available NMIs are allocated to LNSPs ~~and ENMs~~ by AEMO in accordance with the NMI Allocation List.
- ~~(c)~~ Blocks of available NMIs are allocated and reserved for ENMs by AEMO.
- ~~(b)(d)~~ ~~The~~ An ENM must apply to AEMO for a NMI prior to assuming responsibility for a *child connection point*. AEMO will ~~either issue~~ issue a NMI to the ENM for that *child connection point* ~~from the ENM's allocated list or a unique NMI from an available range~~.
- ~~(e)(e)~~ AEMO may allocate blocks of NMIs to LNSPs and ENMs from any unused range.
- ~~(d)(f)~~ The range 5 XXX XXX XXX has been reserved for use in the gas industry. ~~To avoid the risk of confusion, AEMO has agreed not to issue NMIs commencing with 5.~~
- ~~(e)(g)~~ The range 9 XXX XXX XXX has been reserved as a “break-out” if it becomes necessary to move to an 11 character NMI.

2.2. Issue of NMIs by LNSPs and ENMs

- ~~(a)~~ For each new *connection point*, or *child connection point* (as applicable), ~~;~~
- ~~(i)(a)~~ ~~The~~ FRMP must apply to the relevant LNSP, or ENM (as applicable) for a NMI prior to assuming responsibility for the *connection point*, or child connection point (as applicable) and the LNSP, or ENM (as applicable) must issue a NMI to the FRMP for that *connection point*, or child connection point (as applicable), from the LNSP's allocated list, or as provided by AEMO (for a child connection point).
- ~~(ii)~~ ~~The ENM must apply to AEMO for NMI prior to assuming responsibility for the child connection point. AEMO will either issue a NMI to the ENM for that child connection point from the ENM's allocated list or a unique NMI from an available range.~~
- (b) The LNSP or ENM (as applicable) must register the NMI for the *connection point* or *child connection point* (as applicable) in MSATS in accordance with the CATS and WIGS Procedures.

3. NMI STRUCTURE

- ~~(i)(a)~~ Generally, the NMI is an all numeric, ten (10) character identifier. The key attributes of a NMI are:
 - (i) The NMI must embody only numeric characters, except as explicitly provided in this Procedure, and must not contain spaces.
 - (ii) Where alphanumeric characters are allowed, the letters “O” and “I” are not permitted in order to avoid confusion with the numbers 0 and 1.
 - (iii) “W” is ~~a reserved character to be used~~ as the fifth character of the allocated identifier for wholesale *transmission connection metering points* only. It may only be used if the NMI is allocated from an alphanumeric block.
 - (iv) Embedded characters or meanings must not be used in allocating NMIs.
 - ~~(v)~~ ~~Where AEMO has allocated a block of NMIs to an LNSP or an ENM, the LNSP or the ENM (as applicable) must only use numeric characters in the allocated NMIs unless AEMO has directed the block to be alphanumeric.~~
 - ~~(vi)~~ ~~Where AEMO has allocated a block of NMIs to an LNSP or an ENM, and directed the block to be alphanumeric, the LNSP or the ENM (as applicable) may use numeric or alphanumeric characters in the NMIs allocated to the market.~~
- ~~(i)(b)~~ The NMI may be used in conjunction with other identifiers or suffixes. These include:

- (i) The NMI Checksum, a single numeral used to assist with data validation when the *NMI* is manually entered into a computer system.
- (ii) The NMI Datastream suffix used to identify a particular Datastream associated with a *connection point*.
- ~~(k)~~(c) The base *NMI* is ten characters. In some circumstances the NMI Checksum is appended to the *NMI* to form an eleven-character *NMI*, or the two-character NMI Datastream suffix may be appended to form a twelve-character *NMI*. The NMI Checksum is not used with the Datastream suffix because the Datastream suffix is intended for use only with electronic data transfer.
- ~~(j)~~(d) All *NMIs* issued for *connection points* which become contestable after 1 January 2001 are required to be all numeric.
- ~~(m)~~(e) The all-numeric requirement applies to the basic ten character *NMI*, and not to other suffixes used with the identifier.
- ~~(n)~~(f) *Connection points* that were contestable prior to 1 January 2001 were allocated with an alphanumeric *NMI*.
- ~~(o)~~(g) TNSPs may continue to allocate alphanumeric *NMIs* from *NMI* blocks supplied to them prior to 1 January 2001. Wholesale *connection points* (LR = POOL) will continue to have alphanumeric *NMIs* issued.

4. NMI REGISTERS

NSPs and ENMs must maintain a register of *NMIs* assigned by them to *connection points* of ~~f~~ child *connection points*.

5. NMI CHECKSUM

- (a) To reduce the occurrence of incorrect transfers attributable to NMI data entry errors, a one digit NMI Checksum has been implemented.
- ~~(b) — The NMI Checksum is a mandatory field whenever a Change Request is submitted to MSATS.~~
- ~~(e)~~(b) Sample java code for an implementation of the NMI Checksum is provided in Appendix A. A general form of the algorithm used to create the NMI Checksum is:
 - (i) Double the ASCII value of alternate digits beginning with the right-most digit.
 - (ii) Add the individual digits comprising the products obtained in sub-paragraph (i) to each of the unaffected ASCII value digits in the original number.
 - (iii) Find the next highest multiple of 10.
 - (iv) The check digit is the value obtained in sub-paragraph (ii) subtracted from the value obtained in sub-paragraph (iii). If the result of this subtraction is 10, the check digit is 0.
- (c) **Appendix B** provides a worked example of the algorithm and a list of thirty *NMIs* with NMI Checksums calculated by the algorithm.
- (d) The NMI Checksum is always a numeric character.
- (e) The NMI Checksum is not mandatory when transferring NMI identified data electronically between Participants. It is focussed on applications where data entry occurs and there is a risk of character transposition, for example, from paper to electronic systems or through an interactive telephone service.
- (f) When publishing a *NMI* for End Users, the *NMI* will appear in its 11-character format, and the NMI Checksum will be the final character of the *NMI*.

6. DATASTREAM SUFFIX

- (a) *Settlements* relies on the collection and delivery of large volumes of *metering data*. For any particular *connection point* there could be multiple *energy* measurement elements and data recorders with multiple channels. Accurate identification of Datastreams is essential. The Datastream suffix provides identification at the measurement element level for all Datastreams from the *connection point* identified by the *NMI*.

- (b) The Datastream suffix is a two-character identifier used in conjunction with a *NMI* to identify a particular Datastream. It allows differentiation of measurement quantities at a *metering point*, and differentiation of quantities between different measurement elements or registers at a *connection point*.
- (c) A twelve-character *NMI* identifies the *connection point* (first ten characters) and associated Datastream (Datastream suffix as the last two characters).
- (d) The Datastream suffix has retained alphanumeric characters, even when both characters are numerals, because an all numeric structure could not accommodate the variety of data types or number of *meters* that could be required for a *connection point*.
- (e) The Datastream suffix is only used between Participants, and is not used in conjunction with the *NMI Checksum*. The Datastream suffix allows Participants to identify data at a sub-*connection point* level and to identify the individual sources of *metering data* to maintain necessary audit trails.

7. DATASTREAM SUFFIX FOR INTERVAL METERING DATA

- (a) *Interval metering data* may be sourced from *metering installations* type 1 to 5 or 7. *Metering data* from a type 6 *metering installation* that has been transformed through a profiling algorithm into TIs is also identified as *interval metering data*.
- (b) *Interval metering data* is identified in the Datastream suffix by a first character that is alpha [A to H, J to N, P to Z].
- (c) Identifiers in the ‘Master’ column in Table 1 are those normally used in the *NEM*. Where a *check meter* is required (type 1 & 2 *metering installations*), identifiers from the ‘Check’ column are used for the *check meter*. Where the data from the ‘Master’ and ‘Check’ *metering installations* has been averaged in accordance with the *NER*, the ‘Ave’ column identifiers are used. Where only the difference between import and export is required, the ‘Net’ column identifiers are used.

Net Data Will Be Accepted. Net is N = (E-B).

Table 1 Datastream Suffixes for Interval Metering Data

	First character				Second character
	Ave	Master	Check	Net	
IMPORT kWh	A	B	C	N	Meter numbers or measuring elements are to be 1-9 then A-H, J-N, P-Z
EXPORT kWh	D	E	F		
IMPORT kvarh	J	K	L	X	
EXPORT kvarh	P	Q	R		
KVAh	S	T	U		
Power Factor pF		G			
Q Metering Qh		H	Y		
Par Metering parh		M	W		
VOLTS (or V ² h) or Amps (A ² h)		V	Zz		

- (d) Where a *meter* has multiple measurement elements, the convention for the population of the second character of the Datastream Suffix is:
 - (i) Increment the second character by one if the first character is the same. For example, use E1 and E2 if both elements are export kWh, and B1 and B2 if they are both import kWh.
 - (ii) Use the same second character if the first character is different. For example, use E1 and B1 if they are export kWh and import kWh respectively.

Examples:

2727000011 E2 relates to Export kWh data from either meter no.2 (single element) or element 2 of meter no.1 (twin element) pertaining to the *connection point* with the *NMI* of 2727000011. Refer 11.4 and 11.5 for diagrammatic examples.

TTTTW00015 B1 relates to Import kWh *interval metering data* from meter no.1 pertaining to a wholesale *connection point* with the *NMI* of TTTTW00015.

7.1. Datastream Suffix for Accumulated Metering Data

- (a) If the first character of the Datastream suffix is numeric [1 to 9] the attached data is *accumulated metering data* from a type 6 *metering installation*.
- (b) The Datastreams identified by characters 1 to 6 are active energy (kWh). Datastreams identified with 7, 8, or 9 are as defined by the LNSP or the ENM (as applicable).

Table 2 Datastream Suffixes for Accumulated Metering Data

First Character	Second Character
1	First Datastream
2	Second Datastream
3	Third Datastream
4	First controlled load Datastream
5	Second controlled load Datastream
6	Third controlled load Datastream
7	First LNSP/ENM defined Datastream
8	Second LNSP/ENM defined Datastream
9	Third LNSP/ENM defined Datastream

Examples:

8877886644 1A relates to consumption energy data from meter A (~~the~~(the 10th meter at the *metering installation*), register 1 applicable to a *connection point* with the *NMI* of 8877886644.

8866448877 43 relates to consumption energy data from a controlled circuit register in the 3rd meter at the installation, the data pertaining to a *connection point* with the *NMI* of 8866448877.

7.2. Wholesale Connection Points

- (a) A wholesale *connection point* is a *connection point* where:
~~<LR-LR = POOL* (where the "*" is a wildcard for the region= POOL* -> The "*" is a wildcard for the region.~~
)
- (b) For a wholesale *connection point* a *NMI* must be assigned to each individual physical or logical metering point that contributes to the wholesale *connection point*. This requirement is to facilitate a drill down to Datastreams where AEMO is obliged to audit or otherwise investigate energy flows for a wholesale *connection point*.
- (c) AEMO assigns the *NMIs* for *regulated interconnectors*.
- (d) When the *metering point* doesn't align with the physical *connection point*, the *NMI* for the *connection point* is used to identify a logical *metering point*. Each *metering point* that contributes to the logical *metering point* must be assigned a separate *NMI*. The TNSP is responsible for determining the algorithm used to relate the logical *metering point* for a physical connection to the *metering point(s)* that contribute data for the physical connection.
- (e) Any Participant intending to apply a logical *meter* to a *connection point* must contact AEMO's Registration Desk to seek approval prior to entering any data into MSATS.

8. CONNECTION POINTS WITH **CHECK TYPE 1** METERING

- (a) For *connection points* with a type 1 *metering installation*, the *NMI* must be assigned to every averaged *energy flow* pertaining to each *connection point*.
- (b) A type 1 *metering installation* requires a duplication of metering, voltage and current sources in accordance with the *NER*. The *Datastreams* from one *metering installation* are designated 'Master' and from the other *metering installation* are designated 'Check'.¹
- (c) When both *Datastreams* are from measurement systems of identical accuracy standards, the *NER* require that the *energy Datastream* submitted for *settlements* be the average of the values from the master *meter* and *check meters*. In this case the *Datastream* suffixes will have an initial character A (import) or D (export) or N (net).
- (d) If the *check meter* is of a lower accuracy standard than the *metering installation*, only the 'Master'¹ *Datastream* is submitted, in which case the *Datastream* suffixes will have an initial character B (import) or E (export) or N (net).

9. ~~CONNECTION POINTS WITH TYPE 2~~ METERING

- ~~(a)~~(e) The *NER* requires that a type 2 *metering installation* has partial *check metering*. The obligations for partial *check metering* can be met by a *check meter*, in which case the *Datastreams* will be identified as for a type 1 *metering installation*.
- ~~(b)~~(f) Alternatively, the arrangement of a partial *check metering* may be as agreed between *AEMO* and the *MC*. In a partial *check metering* scheme each *Datastream* used needs to be separately identified. It is possible that a number of *NMIs* will be used in a partial *check metering* scheme to identify logical metering points, and a particular meter and instrument transformer combination may be a component of more than one partial *check meter*. The actual arrangements will be part of the scheme submitted by the *MC* to *AEMO* for approval.

9. NMI RULES

9.1. NMI Allocation and Verification

- (a) All *NMIs* must be allocated to End User *connection points* by *LNSPs* or *ENMs* (as applicable), and:
 - (i) The *LNSP* must verify that the *NMI* is correctly associated with the *TNI* in *MSATS*.
 - (ii) The *ENM* must verify that the *NMI* is correctly associated with the correct *embedded network* and *Parent NMI*, and have the same *TNI Code* as the *Parent NMI* in *MSATS*.
- (b) When an *Embedded Generator* registers as a *Market Generator* and *AEMO* determines that a *virtual transmission node* is required for the *Embedded Generator*, *AEMO* will provide an appropriate *TNI* to the *LNSP* and the *LNSP* must assign this *TNI* to the *Embedded Generator connection point*.
- (c) When a *Generator* with one or more *generating units* within an *embedded network* registers as a *Market Generator* in respect of those *generating units* and *AEMO* determines that a *virtual transmission node* is required for those *generating units*, *AEMO* will provide the appropriate *TNI* to the *ENM* and the *ENM* must assign this *TNI* to the *Generator Child NMIs*.

9.2. NMI Decommissioning

- (a) A *NMI* in the *metering register* can only be recorded as de-commissioned in the *metering register* when:
 - (i) a *connection point* is abolished;
 - (ii) the *connection point* changes from the *LV* to the *HV* side of the *service transformer*;
 - (iii) a *child connection point* becomes directly connected to the *LNSP's network*;

¹ Refer to Table 1.

- (iv) a connection point directly connected to the LNSP's network becomes an off-market embedded network connection;
- (v) a connection point directly connected to the LNSP's network becomes a child connection point; or
- (vi) the physical location of a connection point changes.
- (b) When a NMI is allocated to a builder's temporary supply, the same NMI may be re-used for the permanent supply once construction is completed, provided:
 - (i) the final supply arrangements have the same effective connection arrangement to the local network; and
 - (ii) the temporary supply is abolished when the permanent supply connection is energised.
- (c) Subject to section 9.2(a) and (b), a NMI must not be recorded as de-commissioned on the metering register for any of the following reasons:
 - (i) a change of End User;
 - (ii) a reconstruction of the End User supply connection (e.g. overhead moving to underground) in which the two services are not concurrently operational;
 - (iii) a consolidation of meters (e.g. 3 meters → 2 meters) or a relocation of the meter enclosure without changes being made to the location of the measurement transformers;
 - (iv) changes to Participant IT systems, including ENM and LNSP NMI allocation systems;
 - (v) changes to Network Tariffs;
 - (vi) changes to LNSP network boundaries; and
 - (vii) changes to the Role of LNSP or ENM.

Use of the NMI in communications

- ~~All formal confirmation notices between Participants, such as official notices of connection point transfer between FRMPs and data substitutions, must be clearly identified by inclusion of the NMI.~~
- ~~Re-registrations of connection points involving status changes, communications, and meter changes, must include the NMI on all communications.~~

10. NMI RULES

~~Rule 1. Having the NMI in all functions of the market reduces any ambiguity of metering installation identification and fulfils the requirement for an auditable history trail.~~

~~All NMIs must be allocated to End User connection points by LNSPs or ENMs (as applicable). The LNSP is required to verify the NMI is associated with the TNI in MSATS. The ENM is required to verify that the NMI is associated with the correct embedded network and the correct Parent NMI, and have the same TNI Code as the Parent NMI in MSATS.~~

~~It is recognised that the LNSP is the only party who has the required detailed knowledge of the "local" system to correctly identify the relationship between an End User connection point and a TNI.~~

~~Rule 2. A NMI cannot be changed or reallocated to another connection point.~~

~~NMIs cannot be changed or reallocated to accommodate changes to Participant IT systems, changes to assumed associations, changes to Network Tariffs, changes to LNSP network boundaries or ENM changes or because an LNSP's or ENM's allocation system has changed. NMIs cannot be changed where a Child NMI becomes directly connected to a distribution network or reverts to an embedded network connection.~~

~~While an End User may change their FRMP, the NMI for a connection point remains constant throughout its market life. If a connection point is abolished, the NMI becomes extinct and, hence, each NMI has a start date as well as an end date and associated change control. If an End User changes the physical location of the connection point, a new NMI must be allocated to the new connection point. The “old” NMI will be recorded as de-commissioned on metering register and the “new” NMI will be allocated accordingly.~~

~~If an End User changes or End User details change, the NMI will not be changed.~~

~~If an existing connection point becomes a child connection point the NMI will not be changed.~~

~~If the connection point changes from the LV to the HV side of the service transformer there must be a change of NMI.~~

~~If there is a consolidation of meters (eg. 3 meters → 2 meters) or a relocation of the meter box without changes to the location of the measurement transformers the NMI will remain unchanged.~~

~~A reconstruction of the End User service connection (eg. overhead → underground) in which the two services are not concurrently operational, and without a change of the connection point, does not require a change of NMI.~~

~~When a NMI is allocated to a builder’s temporary supply, the same NMI may be re-used on the permanent supply to the completed building provided:~~

- ~~(a) — the final supply arrangements have the same effective connection arrangement to the local network; and~~
- ~~(b) — the temporary supply is abolished when the permanent supply connection is energised.~~

~~Rule 3. All communications with Participants must include the NMI.~~

~~All Participants must be aware that the NMI is the only identifier to be used for defining specific connection points or metering points. All formal confirmation notices between Participants, such as official notices of connection point transfer between FRMPs and data substitutions, must be clearly identified by inclusion of the NMI.~~

~~Re-registrations of connection points involving status changes, communications, and meter changes, must include the NMI on all communications.~~


11.10. UTILISATION OF NMI FOR AEMO DATA

11.1.10.1. Data Delivery to AEMO (MSATS System)


- (a) Metering data is always provided on an individual NMI Datastream basis.
- (b) Metering data is always provided as net energy flow to MSATS.²

12.11. EXAMPLES OF NMI APPLICATION – INTERVAL METERING DATA

Key to symbols used in sections 11.2 and 12.3:




² See section 13 for details of the conventions for the direction of energy flows.



12.1.11.1. One End User metered on the secondary side of transformer


- One *connection point*
- One End User
- One *meter/measurement element*
- One *NMI*



- Allocated NMI: 2424242424
- Identity of interrogated *metering data*: 2424242424 E1

12.2.11.2. One End User, multiple metered on the secondary side of transformer

- One *connection point*
- One End User
- Four *meters/measurement elements*
- One *NMI*




- Allocated *NMI*: 3131313131
- Identity of individual interrogated *metering data*:

3131313131	E1
3131313131	E2
3131313131	E3
3131313131	E4

12.3.11.3. One End User, previously two tariff metering, e.g. general supply & off-peak on secondary side of transformer

- One *connection point*
- One End User
- Two *meters/measurement elements*
- One *meter* with a load control device
- One *NMI*




- Allocated *NMI*: 5656565656
- Identity of individual interrogated *metering data*:

5656565656	E1
5656565656	E2

12.4.11.4. One End User, two controlled loads, one twin element meter


- One *connection point*
- One End User
- Two *meters*: one twin element with a Controlled Load and one single element with a Controlled Load
- One *NMI*



- Allocated *NMI*: 5656565656
- Identity of individual interrogated *metering data*:
 5656565656 E1
 5656565656 E2
 5656565656 E3

12.5.11.5. One End User, two twin element meters


- One *connection point*
- One End User
- Two twin element *meters*
- One *NMI*



- Allocated *NMI*: 5656565659
- Identity of individual interrogated *metering data*:
 5656565659 E1
 5656565659 E2
 5656565659 E3
 5656565659 E4

12.6-11.6. One End User, multiple meters on secondary side of multiple transformers in the same substation building an LV switchboard in common switchroom


- One *connection point*
- One End User
- Three *meters/measurement elements*
- One *NMI*



- Allocated *NMI*: 5656565656
- Identity of individual interrogated *metering data*:
 5656565656 E1
 5656565656 E2
 5656565656 E3

12.7-11.7. Three End Users, metered on secondary side of multiple transformers in the same substation building

- Three *connection points*
- Three End Users
- One *meter/measurement element* per connection point
- Three *NMIs*




- Allocated *NMIs*:
 5656565656
 5656565657
 5656565658

- Identity of individual interrogated *metering data*:
 5656565656 E1
 5656565657 E1
 5656565658 E1

12.8.11.8. One End User, two separate HV supplies to two separate substations, both metered on secondary side of the transformers


- Two LV *connection points*
- One End User
- One *meter/measurement element per connection point*
- Two *NMIs*



- Allocated *NMIs*:
 5656565656
 5656565657
- Identity of individual interrogated *metering data*:
 5656565656 E1
 5656565657 E1

12.9.11.9. One End User, two separate substations adjacent to each other or one single substation with two separate transformers in a single substation, with a “normally open” point separating the HV supplies into two sources


- Two *connection points*
- One End User
- One meter/measurement element per *connection point*
- Two *NMIs*



- Allocated *NMIs*:
5656565656
5656565657
- Identity of individual interrogated *metering data*:
5656565656 E1
5656565657 E1

12.10.11.10. One End User, two separate substations adjacent to each other or one single substation with two separate transformers, with the HV supply originating from a single source


- Two *connection points*
- One End User
- One *meter*/measurement element per *connection point*
- Two *NMIs*



- Allocated *NMIs*: 5656565656
5656565657
- Identity of individual interrogated *metering data*: 5656565656 E1
5656565657 E1

12.11.11.11. One End User, two separate substations not adjacent to each other but on same premises


- Two *connection points*
- One End User
- One *meter/measurement element per connection point*
- Two *NMIs*



- Allocated *NMIs*: 5656565656
5656565657
- Identity of individual interrogated *metering data*: 5656565656 E1
5656565657 E1

12.12.11.12. Multiple End Users, High rise building


- Multiple ~~physical~~ connection points, with all deemed to be at physical connection point c in the diagram.
- Five diagram.
- Five individually metered End Users
- One *meter*/measurement element per *connection point*
- Five *NMIs*



- Allocated *NMIs*:
 - PPPP5656567801
 - PPQQ5656987652
 - PRRR5656000043
 - PRRR5656000044
 - PRRR5656000045
- Identity of individual interrogated *metering data*:
 - PPPP5656567801 E1
 - PPQQ5656987652 E1
 - PRRR5656000043 E1
 - PRRR5656000044 E1
 - PRRR5656000045 E1

12.13.11.13. One End User with multiple supply points


- Two *connection points*
- One End User
- One *meter/measurement element per connection point*
- Two *NMIs*. ~~The *NMI* for the LV supply was allocated after the introduction of numeric *NMIs*.~~
- There are two separate *connection points*, therefore, two separate *NMIs* irrespective of whether the DLFs and supplying TNIs are the same.



- Allocated *NMIs*: 8899778999
NTTT8899123456
- Identity of interrogated *metering data*: 8899778999 E1
NTTT8899123456 E1

12.14.11.14. One End User with Standby Supply


- Two *connection points*
- One End User
- One *meter/measurement element per connection point*
- Two *NMIs*
- There are two separate *connection points*, therefore, two separate *NMIs* irrespective of whether the DLFs and supplying TNIs are the same.



- Allocated *NMIs*: SHHH5656333322
SHHH5656444441
- Identity of interrogated *metering data* is: SHHH5656333322 E1
SHHH5656444441 E1

12.15.11.15. One End User or Participant, Wholesale Metering at Transmission Node


- One *connection point*
- One End User or Participant
- Five *meters* (one *meter/measurement element per metering point*, with summated *transformer check metering*). Four of the *meters* are official *billing meters*, the other *meter* is for data checking and validation purposes.
- Five *NMIs*



- Allocated *NMIs*: VVVVW00001
VVVVW00002
VVVVW00003
VVVVW00004
VVVVW00005
- Identity of individual interrogated *metering data*: VVVVW00001 E1
VVVVW00002 E1
VVVVW00003 E1
VVVVW00004 E1
VVVVW00005 F1

12.16.11.16. One End User or Participant, Wholesale Metering at Transmission Node

- One *connection point*
- One End User or Participant
- One physical *meter*/measurement element installed at different location to the wholesale boundary *connection point*.
- One logical *meter*/measurement element. The logical *meter* corrects the physical *meter* for *transmission line* and *transformer (T/F1)* losses.
- Two *NMIs*. Only the logical *meter* is recorded against the *connection point* in MSATS.



- Allocated *NMIs*: TTTTW00001
TTTTWL0002
- Identity of individual interrogated *metering data*: TTTTW00001 E1
TTTTWL0002 E1


The audit trail of the logical *meter* is maintained through the algorithm and its reference to *metering data* from the physical *meter*.

[The use of a logical *meter* must be approved by AEMO.](#)

~~Any Participant intending to apply a logical *meter* to a *connection point* must contact AEMO's Registration Desk to seek approval prior to entering any data into MSATS.~~

12.17.11.17. One End User, Wholesale Metering at Transmission Node


- One *connection point*. This is a type1 *metering installation* at a wholesale boundary point.
- One End User
- Two *meters*/measurement elements
- One *NMI*. The *NMI* is assigned to the *metering point*.



- Allocated *NMI*: TTDDW00015
- Identity of individual interrogated *metering data*:
 - Master *meter* (Import) TTDDW00015 B1
 - Check *meter* (Import) TTDDW00015 C1

12.18.11.18. Street Lighting (Type 7 Metering Installation)

- Multiple unmetered connections, one *market connection point*.
- One End User.
- One type 7 *metering installation*.
- One *NMI*.
- All lamps are supplied from a single *transmission node*.
- All lamps have the same TNI, DLF, FRMP and LNSP.




- Allocated *NMI*: 5555565656
- Identity of individual interrogated *metering data*: 5555565656 E1

13.12. EXAMPLES OF NMI APPLICATION – ACCUMULATED ENERGY DATA

13.1.12.1. Single Meter with Single Datastream


- Only one Datastream available, identified by 11. Only one Datastream, denoted by first character 1, and only one *meter* denoted by second character 1.



- Allocated *NMI*: 5656565656
- Identity of individual interrogated *metering data*: 5656565656 11

13.2.12.2. Two Meters each with Single Datastream


- The Datastream from the first *meter* is identified by 11, and from the second *meter* by 12.



- Allocated *NMI*: 5656565656
- Identity of individual interrogated *metering data*:
5656565656 11
5656565656 12

13.3.12.3. Two Meter Installation, One Meter Recording Consumption for a Controlled Load


- The data for *meter* one is from the first Datastream, hence suffix 11.
- The data for *meter* two is from the first Controlled Load Datastream, hence suffix 42.



- Allocated *NMI*: 5656565656
- Identity of individual interrogated *metering data*:
5656565656 11
5656565656 42

13.4.12.4. Three Datastream, One Meter with Single Measurement Element


- The *meter* has a three-rate Datastream (high, shoulder, and low rates). As there is only one *meter*, each of the suffixes will have the final character set to 1 to denote that the *metering data* has originated from the same *meter*.
- Each Datastream is numbered as the reader loads *metering data* from them – for a mechanical three-rate Datastream, from top to bottom, or left to right, and for an electronic Datastream in the order in which they scroll.



- Allocated *NMI*: 5656565656
- Identity of individual interrogated *metering data*:
 5656565656 11
 5656565656 21
 5656565656 31

13.5.12.5. Multi-function Meter


- Multi-function *meter* with two measurement elements.
- Each measurement element has a single *energy* Datastream, which requires two data suffixes. As there is only one *meter*, each of the suffixes will have the final character set to 1 to denote that the *metering data* has originated from the same *meter*. The Controlled Load data will be denoted by a 41 as originating from the first Controlled Load Datastream, and the continuous circuit will be denoted by 11.



- Allocated *NMI*: 5656565656
- Identity of individual interrogated *metering data*:
 5656565656 11
 5656565656 41

13.6.12.6. Two Multi-function Meters

- Two multi-function *meters* where the controlled circuits have the same switching control.




- Allocated *NMI*: 5656565656
- Identity of individual interrogated *metering data* (*meter 1*):
 5656565656 11
 5656565656 41
- Identity of individual interrogated *metering data* (*meter 2*):
 5656565656 12
 5656565656 42

14.13. ENERGY DIRECTION FLOWS

The following conventions are used in the *NEM*:

- (a) All flows are specified by reference to their direction to or from the *market*. Hence:
 - (i) ~~(i)~~ — All *energy* from the *market* is considered export (i.e. *energy* consumed by an End User is export) (**Export**).
 - (ii) ~~(ii)~~ — All *energy* into the *market* is considered import (i.e. the *energy generated* into the *market* is import) (**Import**).
- (b) AEMO shall define the import and export *energy* flows for *interconnectors* on a case-by-case basis.
- (c) For the purposes of MSATS, ‘Net’ *energy* is derived as: Net = Export - Import
 - (i) Hence, the net *energy* for *generation* is negative (in a net quantity) and an End User’s *energy* is positive (in a net quantity).
 - (ii) For Accumulation Meter Datastreams, this means that the *energy* values for import (*generation*) must be negative [in the MDM Data File](#).



The same convention is used for kvarh, i.e.:
 kvarh supplied to an End User are export kvarh; and
 kvarh received from an End User are import kvarhs.

15.14. ALLOCATION OF NMIS FOR TYPE 7 METERING INSTALLATIONS

Schedule 7.4 of the NER and ~~the section 12 of~~ Metrology Procedure: Part B establish the framework for type 7 metering installations.

15.1.14.1. Common Requirements across the NEM

- (a) Each type 7 metering installation applies to a unique combination of FRMP, End User, TNI, DLF, and LNSP.
- (b) The NMI may contain different agreed ~~market~~ Unmetered Device loads or Unmetered Device types. One NMI is required for each type 7 metering installation. Individual Unmetered Device loads may be added to and removed from the NMI without the need to change the NMIs.
- (c) For each TNI there will be one or more NMIs representing municipal lighting loads, and several other NMIs representing the various utilities who have Unmetered Device loads in the geographic area serviced by the TNI.
- (d) New NMIs must only be created where one or more Unmetered Device loads with a unique and previously unregistered set of attributes (FRMP, End User, TNI, DLF, LNSP) are to be put into service.
- (e) A NMI may be abolished if the Unmetered Device load is removed (eg-e.g. street turned into park, and lighting removed) or the Unmetered Device load is transferred to another NMI. (eg-E.g. due to network re-arrangements).
- (f) A change of one attribute (FRMP, TNI, DLF, LNSP), or a change of End User, will not of its own require an abolition of the NMI.
- (g) The NER and Metrology Procedure: Part B provide for the allocation of NMIs to broad classes of Unmetered Device connection points provided that certain attributes required for settlements remain unique.
 AEMO expects that each LNSP has a procedure for the allocation of NMIs for Unmetered Device supplies, which will be available for review by the Jurisdiction or AEMO on request.
- (h) A procedure for the allocation of NMIs for street and public lighting across a geographic area must include the following steps:
 - (i) Define the geographic area supplied from a transmission node.
 - (ii) Subdivide the Unmetered Device supplies within this geographic area according to End Users. If necessary, sub-divide these Unmetered Device supplies to take account of variations of DLF that apply across the area.
 - (iii) If necessary, subdivide these Unmetered Device supplies according to FRMP.
- (i) When considering materiality, the LNSP may allocate streetlights by geographic area, or postcode, or by some other available grouping where the majority of that Unmetered Device load is supplied from a single transmission node.
- (j) Where distribution feeders are commonly supplied from one transmission node, but are regularly moved to another transmission node for maintenance or seasonal reasons, the Unmetered Device NMI can be recorded in MSATS against the transmission node through which the majority of the energy is delivered. This approach is supported by the fact that the calculation of marginal loss factors takes account of seasonal flows at transmission nodes, and that the marginal loss factors for adjacent TNIs where load sharing is possible are unlikely to be significantly different.

APPENDIX A. SAMPLE JAVA CODE FOR NMI CHECKSUM

```

/**
 * Calculates a LUHN-10.
 * <PRE>
 * 1. Double the value of alternate digits beginning with the rightmost digit
 * 2. Add the individual digits comprising the products obtained in step 1 to
 *   each of the unaffected digits in the original number.
 * 3. Find the next highest multiple of 10
 * 4. The check digit is the value obtained in step 2 subtracted from the value
 *   obtained in step 3.
 * 5. END
 * </PRE>
 */
public class LUHN10
{
    /**
     * Value to indicate we have not calculated the luhn yet.
     */
    private static final int NULL_VALUE = -1;

    /**
     * Buffer holding the sequence of digits to use in the calculation.
     */
    private StringBuffer _buffer;

    /**
     * The cached value for the luhn.
     */
    private int _luhn;

    /**
     * Constructor.
     */
    public LUHN10()
    {
        reset();
    }

    /**
     * Resets the calculator to its initial values.
     */
    public void reset()
    {
        _buffer = new StringBuffer();
        _luhn = NULL_VALUE;
    }

    /**
     * Updates the LUHN-10 with specified digit.
     */
    public void update(char d)
    {
        // Append the character
        _buffer.append(d);

        // And, reset the cached luhn
        _luhn = NULL_VALUE;
    }
}

```

```
/**
 * Returns the current LUHN-10 value.
 */
public int getValue()
{
    if (_luhn == NULL_VALUE)
    {
        int v = 0;
        boolean multiply = true;
        for (int i = _buffer.length(); i > 0; i--)
        {
            int d = (int)_buffer.charAt(i - 1);

            if (multiply)
            {
                d *= 2;
            }
            multiply = !multiply;

            while (d > 0)
            {
                v += d % 10;
                d /= 10;
            }
        }
        _luhn = (10 - (v % 10)) % 10;
    }
    return _luhn;
}

public static void main(String[] args)
{
    if (args.length == 0)
    {
        System.out.println("USAGE: LUHN10 nmi");
    }
    else
    {
        LUHN10 luhn = new LUHN10();

        String nmi = args[0];

        for (int j = 0; j < nmi.length(); j++)
        {
            luhn.update(Character.toUpperCase(nmi.charAt(j)));
        }

        System.out.println(nmi + "/" + luhn.getValue());
    }
}
}
```

APPENDIX B. EXAMPLES

This Appendix contains a worked example of the NMI Checksum calculation. An alphanumeric *NMI* is used in the example to illustrate the algorithm's ability to handle all characters that have an ASCII equivalent.

The logic of the algorithm can be summarised as:

Process each character in the *NMI* individually, starting with the right most. For each character:

- (a) Convert the character to its ASCII value
- (b) For the right most character and every second character reading left, double the ASCII value obtained in Step (a).
- (c) Add the individual digits of the ASCII value to a register holding the total added value for the NMI Checksum.

Subtract the total added value register from the next highest multiple of 10. If the result is 10, the checksum is 0, otherwise the result is the NMI Checksum.

The *NMI* for the following worked example is: 1234C6789A

Step 1. Initialise variables used by the process.

Double_This_Char

is a boolean that indicates whether the character currently being processed should be doubled.

Char

is the character currently being processed as it appears in the *NMI*.

ASCII_Char

is the ASCII value of Char

Total

is the running sum of the digits generated by the algorithm.

NMI Checksum

is the final result. At the start of the process:

Double_This_Char = True

because the right most character, and then every second character, is doubled by the algorithm.

Total = 0

Checksum = NULL

Step 2. Read the *NMI* character by character, starting with the right most character.

Char = A

Step 3. Convert the character to its ASCII value.

ASCII_Char = 65

Step 4. Double the ASCII value if the character is the right most of the *NMI* or an alternate.

ASCII_Char = 130

Double_This_Char = Not Double_This_Char

Step 5. Add the individual digits of the ASCII value to the Total After.

Total = Total + 1 + 3 + 0 (i.e. Total = 4)

Performing steps 2 to 5 for each character in our example *NMI* gives the following results:

Table 3 Example NMI Results

Character	Total Before	ASCII Value	Double?	Doubled Value	Total After
A	0	65	Y	130	4 (0+1+3+0)
9	4	57	N	57	16 (4+5+7)
8	16	56	Y	112	20 (16+1+1+2)
7	20	55	N	55	30 (20+5+5)
6	30	54	Y	108	39 (30+1+0+8)
C	39	67	N	67	52 (39+6+7)
4	52	52	Y	104	57 (52+1+0+4)
3	57	51	N	51	63 (57+5+1)
2	63	50	Y	100	64 (63+1+0+0)
1	64	49	N	49	77 (64+4+9)

The value of 'Total After' processing ~~the NMI~~ the NMI is 77.

The next highest multiple of 10 is 80.

Checksum = 80 - 77 = 3.

Further examples: NMIs and Associated Checksums

The following thirty NMI Checksums were calculated by AEMO from the *NMIs* listed in Table 4. The *NMIs* and NMI Checksums are provided to assist Participants in checking their implementation of the NMI Checksum algorithm.

Table 4 NMIs and NMI Checksums

NMI	NMI Checksum	NMI	NMI Checksum
2001985732	8	QAAAVZZZZZ	3
2001985733	6	QCDWW00010	2
3075621875	8	SMVEW00085	8
3075621876	6	VAAA000065	7
4316854005	9	VAAA000066	5
4316854006	7	VAAA000067	2
6305888444	6	VAAASTY576	8
6350888444	2	VCCCX00009	1
7001888333	8	VEEEX00009	1
7102000001	7	VKTS786150	2
NAAAMYS582	6	VKTS867150	5
NBBBX11110	0	VKTS871650	7
NBBBX11111	8	VKTS876105	7
NCCC519495	5	VKTS876150	3
NGGG000055	4	VKTS876510	8